



MICROENER

D.C. SUBSTATION PROTECTIVE RELAY TYPE

DC-PRO - Pro-Line

FDE n°: 19AA0371200 Rev. A

Gestion des modifications

MODIFICATIONS				
Rev.	Description	Date	Vérifié par	Approuvé par
Z1	Création	03/07/2019	AA	LA
A	Diffusion	02/08/2019	NLT	LA

GENERAL UTILIZATION AND COMMISSIONING DIRECTIONS	5
Storage and Transportation	5
Installation	5
Electrical Connection.....	5
Measuring Inputs and Power Supply	5
Outputs Loading.....	5
Protection Earthing	5
Setting and Calibration.....	5
Safety Protection.....	5
Handling	5
Maintenance	5
Waste Disposal of Electrical & Electronic Equipment	5
Fault Detection and Repair.....	5
GENERAL.....	6
Current measurement.....	6
Line voltage measurement.....	6
Frame earth fault current measurement	6
Frame voltage measurement	6
Main Unit - Power Supply	6
Remote Unit - Power Supply	6
REMOTE UNIT	7
Front View	7
Rear View	7
Touch home measures settings (available only via MSCom2)	9
Erreur ! Signet non défini.	
SIGNALIZATION	11
Leds on Main Unit.....	11
Leds on Remote Unit.....	11
Leds Configuration.....	12
Example: Change settings for "Led5"	15
USER VARIABLES.....	19
Name.....	19
User Descr.....	19
Linked functions	19
OpLogic.....	19
Timer.....	19
Timer type.....	19
Logical status.....	19
Example: Setting "User Variable"	20
COMMANDS	25
MAXIMUM VALUES (AVAILABLE ONLY VIA MSCOM2)	26
ENERGY	26
LAST TRIP	26
PARTIAL COUNTERS	27
TOTAL COUNTERS.....	28
EVENTS	29
Events	29
SYSTEMS (SYSTEM PARAMETERS)	31
System Parameters	31
Configuration Expansions.....	31
General Communication parameters	31
Ethernet Communication parameters.....	31
Information parameters	31
Input channel characteristics	32
SETTINGS.....	33
Password.....	33
Menu: Comm. (Serial Communication protocols options)	34

Menu: HMI (Human Machine Interface)	36
USB	38
IP Protocols	38
IEC61850 Protocol	38
Modbus TCP Protocol	38
NTP (Time/Date synchronization parameters)	38
Time Zone/DayLight (Options)	38
File system and disks management	39
Function: T> (Thermal Image F49)	39
Function: 1I> (First Overcurrent Element F50/51)	42
Function: 2I> (Second Overcurrent Element F50/51)	46
Function: 3I> (Third Overcurrent Element F50/51)	47
Function: 4I> (Fourth Overcurrent Element F50/51)	48
Function: Iis (Instantaneous Current Element)	49
Function: 1delta-I (First Current Step Element)	49
Function: 2delta-I (Second Current Step Element)	50
Function: 1di/dt (First Current Rate of Rise Element)	51
Function: 2di/dt (Second Current Rate of Rise Element)	52
Function: Rapp (Impedance monitoring - di/dt dependence)	53
Function: Iapp (Current monitoring with di/dt dependence)	54
Function: 1Ig (First Frame Fault Element)	55
Function: 2Ig (Second Frame Fault Element)	56
Function: RCL (Automatic Reclosure)	57
Function: 1U> (First OverVoltage Element F59)	58
Function: 2U> (Second OverVoltage Element F59)	58
Function: 1U< (First UnderVoltage Element F27)	58
Function: 2U< (Second UnderVoltage Element F27)	59
Function: UL< (Line Voltage Presence)	59
Function: Wi (Circuit Breaker maintenance level)	60
Function: TCS (Trip Circuit Supervision)	62
Function: IRF (Internal Relay Fault)	63
Function: RT (First Element Remote Trip)	63
Function: RTX (Second Element Remote Trip)	64
Function: BrKFail (Breaker Failure)	64
Function: Dia-I (Diagnostic analog inputs current)	65
Function: Wh (Energy counter Pulse)	65
Function: Self Trip (Spontaneous trip)	66
Function: Oscillo (Oscillographic Recording)	67
Function: L/R CB Cmds (Local Remote Close Breaker Command)	73
Function: CB-L (CB Lock)	74
Function: LT (Automatic Line Test)	75
Function: ExtResCfg (External Reset Configuration)	78
Function: Dia C/B (Diagnostic C/B position)	78
Function: auxRCmds (Auxiliary Remote Commands)	79
INPUT – OUTPUT (VIA SOFTWARE MSCom2)	80
Digital Input	80
“DI” Configuration parameter available (via keyboard or MSCom2 software)	80
Function available	81
“DI” Configuration - via MSCom2 software	83
Outputs Relay	85
Analog output	85
“OutCfg” Outputs Configuration - via MSCom2 software	86
USERVAR	91
Configuration – via MSCom2 software	91
DATE AND TIME	98
Clock synchronization	98
BATTERY	98
MAINTENANCE	98
POWER FREQUENCY INSULATION TEST	98
TERMINAL BLOCKS (WIRING DIAGRAM)	99
Power Supply	99
Measurement Inputs	99
Digital Inputs	100
Analogic Outputs	100



Téléphone : +33 1 48 15 09 09
www.microener.com

**OPERATION MANUAL
D.C. SUBSTATION PROTECTIVE
RELAY TYPE**

DC PRO – PRO-LINE

**FDE N°:
19AA0371200**

**Rev. A
Page 4 / 107**

Output Relays	100
Communications terminals	100
OVERALL DIMENSIONS	103
Remote Unit	103
Main Unit.....	104
SPARE PARTS.....	105
Main Unit.....	105
Remote Unit	105
TOOLS	106
ELECTRICAL CHARACTERISTICS	107

GENERAL UTILIZATION AND COMMISSIONING DIRECTIONS

Always make reference to the specific description of the product and to the Manufacturer's instruction.
Carefully observe the following warnings.

Storage and Transportation

Must comply with the environmental conditions stated in the product's specification or by the applicable IEC standards.

Installation

Must be properly made and in compliance with the operational ambient conditions stated by the Manufacturer.

Electrical Connection

Must be made strictly according to the wiring diagram supplied with the Product, to its electrical characteristics and in compliance with the applicable standards particularly with reference to human safety.

Measuring Inputs and Power Supply

Carefully check that the value of input quantities and power supply voltage are proper and within the permissible variation limits.

Outputs Loading

Must be compatible with their declared performance.

Protection Earthing

When earthing is required, carefully check its effectiveness.

Setting and Calibration

Carefully check the proper setting of the different functions according to the configuration of the protected system, the safety regulations and the co-ordination with other equipment.

Safety Protection

Carefully check that all safety means are correctly mounted, apply proper seals where required and periodically check their integrity.

Handling

Notwithstanding the highest practicable protection means used in designing M.S. electronic circuits, the electronic components and semiconductor devices mounted on the modules can be seriously damaged by electrostatic voltage discharge which can be experienced when handling the modules.

The damage caused by electrostatic discharge may not be immediately apparent but the design reliability and the long life of the product will have been reduced. The electronic circuits produced by M.S. are completely safe from electrostatic discharge (8 KV IEC 255.22.2) when housed in their case; withdrawing the modules without proper cautions expose them to the risk of damage.

Maintenance

Make reference to the instruction manual of the Manufacturer; maintenance must be carried-out by specially trained people and in strict conformity with the safety regulations.

Waste Disposal of Electrical & Electronic Equipment

(Applicable throughout the European Union and other European countries with separate collection program).
This product should not be treated as household waste when you wish dispose of it. Instead, it should be handed over to an applicable collection point for the recycling of electrical and electronic equipment.
By ensuring this product is disposed of correctly, you will help prevent potential negative consequence to the environment and human health, which could otherwise be caused by inappropriate disposal of this product. The recycling of materials will help to conserve natural resource.

Fault Detection and Repair

Internal calibrations and components should not be altered or replaced.
For repair please ask the Manufacturer or its authorized Dealers.

Misapplication of the above warnings and instruction relieves the Manufacturer of any liability.

GENERAL

Input quantities are supplied via isolated converters with (0–20mA / 4–20mA / 12–20mA) output (overload 25mA).

It is also available two optical inputs for current (IL) and voltage (VL) for direct connection to Microelettrica MHIT converters series, without receivers.

For best accuracy and reliability we recommend to use MHCO – MHIT measuring converters for supply of input.

Current measurement

1 Input 0 - 20mA ≈ 0 - 1In

1 Input 0 - 20(25)mA ≈ 0 - 10(12.5)In

Measuring range 0 - 12.5 times the rated input current (12.5In)

Resolution 16 bits

Current analog input can be selectable:

0-20mA

4-20mA

12-20mA

The ratio from first and second current channel is programmable from 2 to 10.

Line voltage measurement

1 Input 0 - 40mA ≈ 0 - 2Un

Measuring range 0 - 2 times the rated input voltage (2xUn)

Resolution 12 bits

Frame earth fault current measurement

1 Input 0 - 20mA (25mA) ≈ 0 - 1In (0 - 1,25In)

Measuring range 0 - 1 times the rated input current

Resolution 12 bits

Frame voltage measurement

1 Input 0 - 40mA ≈ 0 - 2Un

Measuring range 0 - 2 times the rated input voltage (2xUn)

Resolution 12 bits

Make electric connection in conformity with the diagram reported on relay's enclosure.

Check that input currents and voltages are same as reported on the diagram and on the test certificate.

The auxiliary power is supplied by a built-in fully isolated and self-protected unit.

Main Unit - Power Supply

The relay can be fitted with two different types of **power supply**:

Type 1	24V(-20%) / 110V(+15%) a.c.
Type 2	80V(-20%) / 220V(+15%) a.c.


24V(-20%) / 125V(+20%) d.c.
90V(-20%) / 250V(+20%) d.c.

Before energizing the unit check that supply voltage is within the allowed limits.

Remote Unit - Power Supply


Type	15 ÷ 30 Vdc
------	-------------

The supply for remote MMI unit is available on the main relay (24Vdc – 30W max)
on terminals **73 (-) and 74 (+)**.

REMOTE UNIT**Front View**

Rear View

RS232	Not Used
RS485	Connection to Main Unit
RJ45	Connection to Main Unit
USB	Update Software - Remote Unit
Power Supply	Power Supply




Touch home measures settings (available only via MSCom2)

Through this menu is possible to set the order of parameters (maximum 29) shows in the home page


Example

Open "MSCOM2" program and connect to the relay.

Select "Change Windows" from "Menu" button




Select "Touch home measures settings".





The window configuration will show:

ID	Name	Value
1	Touch row 1	[Actual measurements] -> I (Line Current)
2	Touch row 2	[Actual measurements] -> U (Line Voltage)
3	Touch row 3	[Actual measurements] -> W (Power)
4	Touch row 4	[Actual measurements] -> Term (Thermal Status %Tr)
5	Touch row 5	[Actual measurements] -> Ig (Frame to Ground fault current)
6	Touch row 6	[Actual measurements] -> Ug (Frame to Ground fault voltage)
7	Touch row 7	[Actual measurements] -> Wir (C/B residual interruption energy)
8	Touch row 8	[Actual measurements] -> RS-G (Resistance Screen/Ground)
9	Touch row 9	[Actual measurements] -> A/ms (Current rate of rise)
10	Touch row 10	[Actual measurements] -> Rapp (Impedance monitoring)

Select "Value" related to "Touch row 1" and press right button on mouse, select "Value change":



Select "T>" from combo box and press "OK" (if Password is request, see § Password):



Now on the relay display on line 1 will appear T>.


Available parameters

Stop End Wiev List Empty Empty line I Line Current U Line Voltage W Power Tem Thermal status Ig Frame to Ground fault current Ug Frame to Ground fault voltage RS-G Resistance Screen/Ground A/ms Current rate of rise Rapp Impedance monitoring Wir C/B residual interruption energy +kWh Active Exported energy -kWh Active Imported energy Vv C/B Downstream voltage Vm C/B Upstream voltage Ei C/B remaining energy Ee C/B remaining energy RLin Line resistance T> Thermal image 1I> First overcurrent element 2I> Second overcurrent element 3I> Third overcurrent element 4I> First overcurrent element Iis> Fourth overcurrent element 1dl First current step element 2dl Second current step element 1di/dt First current rate of rise element 1di/dt Second current rate of rise element Rapp Impedance monitoring di/dt dependence Iapp Current monitoring with di/dt dependence 1Ig First frame fault element 2Ig Second frame fault element RCL Recloser 1U> First Overvoltage element 2U< Second Overvoltage element 1U< First Undervoltage element 2U< Second Undervoltage element Ni Trip number arcs interrupts operations Ne Trip number electrical contact operations Nm Trip number mechanical operations of circuit breaker RT Remote Trip TCS Trip circuit supervision IRF Internal Relay Fault BrkF Breaker Failure SelfTrip Spontaneous protection trip AutOp Automatic C/B open AutCl Automatic C/B close ManOp Manual / Intentional C/B open ManCl Manual / Intentional C/B close OvrOp Overall C/B open (automatic + Intentional) OvrCl Overall C/B close (automatic + Intentional) LT Line Test RTX Remote Trip	<i>Actual Measurements</i> <i>Partial Counters</i>	DiaCB1 Input position discremancy AnCB1 Operation Failure OpCB1 Opening operation CICB1 Closures operation OPrCB1 Overall operation (close + open) DiaCB2 Input position discremancy AnCB2 Operation Failure OpCB2 Opening operation CICB2 Closures operation OPrCB2 Overall operation (close + open) DiaCB3 Input position discremancy AnCB3 Operation Failure OpCB3 Opening operation CICB3 Closures operation OPrCB3 Overall operation (close + open) DiaCB4 Input position discremancy AnCB4 Operation Failure OpCB4 Opening operation CICB4 Closures operation OPrCB4 Overall operation (close + open) DiaCB5 Input position discremancy AnCB5 Operation Failure OpCB5 Opening operation CICB5 Closures operation OPrCB5 Overall operation (close + open)
--	---	---

SIGNALIZATION
Leds on Main Unit

4 signal leds are provided:

<i>Nº</i>	<i>Colour</i>	<i>Default Status</i>
<i>Led 1</i>	Green	Not Assigned
<i>Led 2</i>	Yellow	Not Assigned
<i>Led 9</i>	Red	Not Assigned
<i>Led 10</i>	Green	Not Assigned




Local leds settings corresponding at remote leds 1,2 and 9,10.

Leds on Remote Unit

11 signal leds are provided:

<i>Nº</i>	<i>Colour</i>	<i>Default Status</i>
<i>Led Power</i>	Green	Power ON
<i>Led 1</i>	Green	Not Assigned
<i>Led 2</i>	Green	Not Assigned
<i>Led 3</i>	Green	Not Assigned
<i>Led 4</i>	Yellow	Not Assigned
<i>Led 5</i>	Red	Not Assigned
<i>Led 6</i>	Red	Not Assigned
<i>Led 7</i>	Red	Not Assigned
<i>Led 8</i>	Yellow	Not Assigned
<i>Led 9</i>	Red	Not Assigned
<i>Led 10</i>	Green	Not Assigned



In case of auxiliary power supply failure the status of the leds is recorded and reproduced when power supply is restored.

Reset from Illuminated status is manual or automatic (see § Commands and § led configuration)

Leds Configuration

For Leds' programming (only via MSCom2) operate as follows:

Open "MSCOM2" program and connect to the relay.

Select "Change Windows" from "Menu" button



Select "Led Setting"

The window for led configuration will show:

ID	Name	Link enable	Status	Light prog.	Funct. Mode	Functions
1	Led 1 (Read only)	Not linked	Light off	Light on	Volatile	11>
2	Led 2 (Read only)	Not linked	Light off	Light on	Volatile	11s

Name

Led name – for leds position see picture

Link enable

<i>Linked</i>	=	Enable to operate
<i>No Linked</i>	=	Disable

Status

<i>Light-OFF</i>	=	Normal condition
<i>Light-ON</i>	=	When cause appear led is illuminated
<i>Flashing</i>	=	When cause appear led is flashing

Light Prog.

<i>Light-ON</i>	=	When cause appear led is illuminated
<i>Flashing</i>	=	When cause appear led is flashing

Funct. Mode

<i>Volatile</i>	=	When cause disappear led turn-off (Not memorized)
<i>Latched</i>	=	When cause disappear led remain illuminated (memorized)

Functions

Select the function assigned to specific led (see table 1).
It's possible to configure only one function for each led.
For configuration multiple functions use "UserVar" function.

Table 1

T>	Tal T>	(alarm) (trip)	<i>Thermal element</i>
1I>	I1> t1I>	(Start) (Trip)	<i>First overcurrent element</i>
2I>	I2> t2I>	(Start) (Trip)	<i>Second overcurrent element</i>
3I>	I3> t3I>	(Start) (Trip)	<i>Third overcurrent element</i>
4I>	I4> t4I>	(Start) (Trip)	<i>Fourth overcurrent element</i>
Iis	tIis>		<i>Instantaneous current</i>
1di	1dI t1dI	(Start) (Trip)	<i>First Current step element</i>
2di	2dI t2dI	(Start) (Trip)	<i>Second Current step element</i>
1di/dt	1di/dt t1di/dt	(Start) (Trip)	<i>First Current rate of rise element</i>
2di/dt	2di/dt t2di/dt	(Start) (Trip)	<i>Second Current rate of rise element</i>
Rapp	Rapp	(Trip)	<i>Impedance monitoring – di/dt dependance</i>
Iapp	Iapp		<i>Current monitoring with di/dt dependence</i>
1Ig	I1g t1Ig	(Start) (Trip)	<i>First instantaneous Frame Fault element</i> <i>First time delayed Frame Fault element</i>
2Ig	I2g t2Ig	(Start) (Trip)	<i>Second Frame Fault element</i>
RCL	RCL cmd	(Trip)	<i>Reclosure Shot command</i> <i>Autoreclosure in progress</i> <i>Autoreclosure Failure</i> <i>Autoreclosure Lock-out</i> <i>Autoreclosure Ok</i> <i>Autoreclosure Enable</i> <i>Autoreclosure Disable</i>
1U>	1U> t1U>	(Start) (Trip)	<i>First overvoltage element</i>
2U>	2U> t2U>	(Start) (Trip)	<i>Second overvoltage element</i>
1U<	1U< t1U<	(Start) (Trip)	<i>First undervoltage element</i>
2U<	2U< t2U<	(Start) (Trip)	<i>Second undervoltage element</i>
UL<	UL<		<i>Line Voltage Presence</i>
RT	RT tRT	(Trip) (Start)	<i>First Instantaneous Remote Trip</i> <i>First Time delayed Remote Trip</i>
Wi	tWi> Ni alNi Ne alNe Nm alNm		<i>Circuit breaker maintenance level</i> <i>Maximum number of arc chute operation at nominal values</i> <i>Alarm maintenance level of arc chute operation</i> <i>Maximum number of arc contact operation at nominal values</i> <i>Alarm maintenance level of arc contact operation</i> <i>Maximum number of mechanical operation</i> <i>Alarm maintenance level of mechanical operation</i>
TCS	tTCS	(Trip)	<i>Time delayed Trip Circuit Supervision</i>
IRF	IRF tIRF	(Start) (Trip)	<i>Time delayed Internal relay Fault</i> <i>Instantaneous Internal relay Fault</i>
RTX	RTX trTX	(Trip) (Start)	<i>Second Instantaneous Remote Trip</i> <i>Second Time delayed Remote Trip</i>
CB-L	CB-L		<i>C/B reclose Lock-out</i>
BF	BF		<i>Breaker Failure</i>
Wh	+ Wh - Wh		<i>Imported Energy counter Pulse</i> <i>Exported Energy counter Pulse</i>
L/R CB Cmds	cmdOpCB cmdCICB LocRemInc missCBOpe		<i>Open C/B command</i> <i>Close C/B command</i> <i>Local / Remote Inconsistency</i> <i>Missed C/B opening (Digital input missing)</i>
LT	LTPb LTP LTf LTOk LTb LT cmd	(Trip)	<i>Output to operate an external flashing lamp signalling line test in progress</i> <i>Line Test in progress</i> <i>Line Test Failed</i> <i>Line Test OK</i> <i>Line Test Blocked</i> <i>Line Test Command</i>

Gen.Start	Start Generic
Gen.Trip	Trip Generic
UserTriggerOscillo	User Variable for Oscillographic Recording
Gate<0> to Gate<98>	User Variable
MasterOp1	Modbus Master CB1 Open request
MasterCl1	Modbus Master CB1 Close request
MasterOp2	Modbus Master CB2 Open request
MasterCl2	Modbus Master CB2 Close request
MasterOp3	Modbus Master CB3 Open request
MasterCl3	Modbus Master CB3 Close request
MasterOp4	Modbus Master CB4 Open request
MasterCl4	Modbus Master CB4 Close request
MasterOp5	Modbus Master CB5 Open request
MasterCl5	Modbus Master CB5 Close request
CB1Fail	CB1 Failure
CB2Fail	CB2 Failure
CB3Fail	CB3 Failure
CB4Fail	CB4 Failure
CB5Fail	CB5 Failure
CB1missedOp	CB1 Missed Operation
CB2missedOp	CB2 Missed Operation
CB3missedOp	CB3 Missed Operation
CB4missedOp	CB4 Missed Operation
CB5missedOp	CB5 Missed Operation
SelfTrip	Spontaneous protection
t-SelfTrip	Self-Trip time delay
Vcc	Reserved
Gnd	Reserved
ResLog	Reset signal logic
P1	Push-button Open
P2	Push-button Close
0.D1	Digital Input "0.D1"
0.D1Not	Digital Input "0.D1"
to	
0.D4	Digital Input "0.D4"
0.D4Not	Digital Input "0.D4"
1.D1	Digital Input "1.D1"
1.D1Not	Digital Input "1.D1"
to	
1.D15	Digital Input "1.D15"
1.D15Not	Digital Input "1.D15"
2.D1	Digital Input "2.D1"
2.D1Not	Digital Input "2.D1"
to	
2.D15	Digital Input "2.D15"
2.D15Not	Digital Input "2.D15"
0.R1	
to	Output relays
0.R6	
1.R1	
to	Output relays
1.R14	
2.R1	
to	Output relays
2.R14	
DskClean	Internal Disk Clean (disk near to full, clean operation is required)
DskFull	Internal Disk Full (disk full, write should be locked)
DskWR	Internal Disk Write (active during internal disk access)
DskFRMT	Internal Disk Format (active during internal disk format)
DskChk	Internal Disk Check (active during internal disk check procedure)
rDskAttach	Remote disk inserted (USB Key)
rDskDetach	Remote disk not inserted (USB Key)
rDskDtchable	Remote disk removable (USB Key)
rDskClean	External Disk Clean (disk near to full, clean operation is required)
rDskFull	External Disk Full (disk full, write should be locked)
rDskWR	External Disk Write (active during internal disk access)
rDskFRMT	External Disk Format (active during internal disk format)
rDskCHK	External Disk Check (active during internal disk check procedure)
Sync	Date - time synchronization event (active during clock synchronization).
SNTP-DIA	SNTP health status.
SNTP-KOD	Syncro lost by server, Kiss of death. Date-Time need syncro from another server.
Dial	External analog transducer fail (if different from 0-20mA) instantaneous element.
tDial	External analog transducer fail (if different from 0-20mA) time delayed element.
I850Ready	IEC61850 ready to work.
Charat1	Characteristics 1 active
Charat2	Characteristics 2 active
Charat3	Characteristics 3 active
Charat4	Characteristics 4 active

Example: Change settings for "Led5"


Change settings for "LED5" : "Enable", "Flashing", "Latched", "1I>".

Main Windows:


ID	Name	Link enable	Status	Light prog.	Funct. Mode	Functions
1	Led 1 (Read only)	Not linked (0)	Light off (0)	Light on (0)	Volatile (0)	1I> (0)
2	Led 2 (Read only)	Not linked (0)	Light off (0)	Light on (0)	Volatile (0)	1I> (0)
3	Led 3 (Read only)	Not linked (0)	Light off (0)	Light on (0)	Volatile (0)	1I> (0)
4	Led 4 (Read only)	Not linked (0)	Light off (0)	Light on (0)	Volatile (0)	1I> (0)
5	Led 5	Not linked (0)	Light off (0)	Light on (0)	Volatile (0)	1.D1


"Enable"



Select "Link enable" related to "Led 5" and press right button on mouse, select "Value change":





Select "Linked" from combo box and press "OK" (if Password is request, see § Password):



"Flashing"Select "**Light prog**" related to Led 5 and press right button on mouse, select "**Value change**":Select "**Flashing**" from combo box and press "**OK**" (if Password is request, see § Password):

"Latched"Select "**Latched**" related to Led 5 and press right button on mouse, select "Value change":Select "**Latched**" from combo box and press "OK" (if Password is request, see § Password):

"Functions"Select "**Functions**" related to Led 5 and press right button on mouse, select "**Value change**":Select "**1I>**" from combo box and press "**OK**" (if Password is request, see § Password):

USER VARIABLES

The “**USER VARIABLE**” is a result of a logical operation (Or, AND, ecc...), it can be used like other logical output. This operation is possible only via “MSCom2” software.

Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Logical status
------	-------------	------------------	---------	-------	------------	----------------

Name

Internal progressive name

User Descr.

Custom identification label for user variable

Linked functions

Selection functions

OpLogic

Operation Logic = [None, OR, AND, XOR, NOR, NAND, NOT, Ff-SR, Counter, Rise-Up, Fall-Down]

Timer

Time delay (0-10)s, step 0.01s

Timer type

<i>Delay</i>	= Add a delay on output activation. The “Timer” is edge triggered on rise edge.
<i>Monostable P</i>	= Monostable Positive , the positive length of set signal is determinate by the timer
<i>Monostable N</i>	= Monostable Negative , the negative length of set signal is determinate by the timer
<i>Blinking</i>	= The output blink at the specify period
<i>Delay-Fall-Down</i>	= Delay to change edge


Logical status

“User Variable” Logical status


Example: Setting "User Variable"

Open "MSCOM2" program and connect to the relay.

Select "Change Windows" from "Menu" button



Select "USER VARIABLE"




Setting for "USERVAR<0>" : "Current Trip", "1I>,2I>,3I>", "OR", "1", "Monostable".


ID	Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Logical status
1	User Trigger Oscillo	User Trigger Oscillo		None	0	Delay	0
2	UserVar <0>	Current trip	1I>,2I>,3I>	OR	1	Monostable	0

"User description" (User descr.)



Select "User descr" related to "UserVar<0>" and press right button on mouse, select "Value change":



Insert "Current Trip" into box and press "OK":



"Linked Functions"

Select "Linked Functions" related to "UserVar<0>" and press right button on mouse, select "Value change":



Select "**1I>, 2I>, 3I>**" from "Available" box via push-button "<Add>", and press "OK". For remove functions, use push-button ">Remove".


"Operation Logic" (Oplogic)

Select "Oper Logic" related to "UserVar<0>" and press right button on mouse, select "Value change":



Insert "OR" into box and press "OK":




"Timer"

Select "Timer" related to "UserVar<0>" and press right button on mouse, select "Value change":




Select "1" into box and press "OK":




"Timer type"

Select "Timer" related to "UserVar<0>" and press right button on mouse, select "Value change":



Select "Monostable" into box and press "OK":



COMMANDS

Menu		Description	Password
Reset	Leds	Reset of signal Leds	Yes
Reset	Relays	Manual reset of output relays	Yes
Main breaker	Close	Manual C/B closing	Yes
Main breaker	Open	Manu al C/B opening	Yes
Main breaker	Unlock	Unlock the C/B reclosure	Yes
Reset	Event	Manual reset of Events	Yes
Reset	Last Trip	Manual reset of Last Trips	Yes
Reset	Counters	Manual reset of Counters	Yes
Reset	Energy Counters	Manual reset of Energy	Yes
Reset	Historical Fails	Reset of Internal Failure Historic records	Yes
Reset	Ei	Reset of arc chute energy register.	
Reset	Ee	Reset of arc contact energy register.	
Offset On field		External analog transducer offset calibration	
Reset	Term	Reset to zero of the accumulations relevant to Thermal Image and Interruption Energy.	Yes
Test	Leds	Signal Leds test	No
Closure	Breaker C/B1	Closure Breaker CB1	Yes
Opening	Breaker C/B1	Opening Breaker CB1	Yes
Closure	Breaker C/B1	Closure Breaker CB2	Yes
Opening	Breaker C/B1	Opening Breaker CB2	Yes
Closure	Breaker C/B1	Closure Breaker CB3	Yes
Opening	Breaker C/B1	Opening Breaker CB3	Yes
Closure	Breaker C/B1	Closure Breaker CB4	Yes
Opening	Breaker C/B1	Opening Breaker CB4	Yes
Closure	Breaker C/B1	Closure Breaker CB5	Yes
Opening	Breaker C/B1	Opening Breaker CB5	Yes
Force Oscillo recording		Asynchronous command for oscillographic recording	Yes
RS-G	Zero Set	Not used	Yes

MAXIMUM VALUES (AVAILABLE ONLY VIA MSCOM2)

Maximum demand values recorded starting from 100ms after closing of main Circuit Breaker
(updated any time the breaker closes).

I	A	Line current
RLin	ohm	Line resistance
W	kW	Power
Tem	%T	Thermal status as % of the full load continuous operation temperature Tn
Ig	A	Frame to ground fault current
Ug	V	Frame to ground fault voltage
Vm	V	C/B upstream voltage
A/ms		Current rate of rise
Rapp	Ω	Impedance monitoring
Ei	%	C/B arc chute remaining energy
Ee	%	C/B arc contact remaining energy

ENERGY

Real time energy measurements

Display	→ + kWh	(0 – 9999999)	Exported Energy
	→ - kWh	(0 – 9999999)	Imported Energy

LAST TRIP

Function which caused the tripping of the relay plus values of the measurement at the moment of tripping.
The last 50 events are always available on local – remote MMI interface (display or remote communication).
The memory buffer is refreshed at each new relay tripping (FIFO logic).
Each last trip record is also stored on internal / external disk without limits (except the disk capacity).

I	A	Line current
RLin	ohm	Line resistance
W	kW	Power
Tem	%T	Thermal status as % of the full load continuous operation temperature Tn
Ig	A	Frame to ground fault current
Ug	V	Frame to ground fault voltage
Vm	V	C/B upstream voltage
A/ms		Current rate of rise
Rapp	Ω	Impedance monitoring
Ei	%	C/B arc chute remaining energy
Ee	%	C/B arc contact remaining energy
DI-1	A	First current step element
DI-2	A	Second current step element

PARTIAL COUNTERS

Partial counters of the number of operations for each of the relay functions.

T>	Thermal Image
1I>	First overcurrent element
2I>	Second overcurrent element
3I>	Third overcurrent element
4I>	Fourth overcurrent element
Iis	Instantaneous overcurrent
1dI	First current step element
2dI	Second current step element
1di/dt	First current rate of rise element
2di/dt	Second current rate of rise element
Rapp	Impedance monitoring (di/dt dependence)
Iapp	Current monitoring with di/dt dependence
1Ig	First Frame Fault element
2Ig	Second Frame Fault element
RS-G	Cable insulation (Screen-Ground)
RCL	Automatic Reclosure
1U>	First Overvoltage element
2U>	Second Overvoltage element
1U<	First Undervoltage element
2U<	Second Undervoltage element
Ni	Trip number arcs interrupts operations
Ne	Trip number electrical contact operations
Nm	Trip number mechanical operations of circuit breaker
Wi	Circuit Breaker maintenance alarm
TCS	Trip Circuit Supervision
IRF	Internal Relay Fault
RT	First Remote Trip
RTX	Second Remote Trip
BrkF	Breaker failure to open
SelfTrip	Spontaneous protection
AutOp	Automatic C/B Open
AutCL	Automatic C/B Close
ManOp	Manual C/B Open
ManCL	Manual C/B Close
OvrOp	Overall C/B Open (Automatic + Manual)
OvrCL	Overall C/B Close (Automatic + Manual)
LT	Automatic Line Test
DiaCB1	CB1 Input position discrepancy
AnCB1	CB1 Operation failure
OpCB1	CB1 Openings operation
CICB1	CB1 Closures operation
OprCB1	CB1 Overall operation (Close + Open)
DiaCB2	CB2 Input position discrepancy
AnCB2	CB2 Operation failure
OpCB2	CB2 Openings operation
CICB2	CB2 Closures operation
OprCB2	CB2 Overall operation (Close + Open)
DiaCB3	CB3 Input position discrepancy
AnCB3	CB3 Operation failure
OpCB3	CB3 Openings operation
CICB3	CB3 Closures operation
OprCB3	CB3 Overall operation (Close + Open)
DiaCB4	CB4 Input position discrepancy
AnCB4	CB4 Operation failure
OpCB4	CB4 Openings operation
CICB4	CB4 Closures operation
OprCB4	CB4 Overall operation (Close + Open)
DiaCB5	CB5 Input position discrepancy
AnCB5	CB5 Operation failure
OpCB5	CB5 Openings operation
CICB5	CB5 Closures operation
OprCB5	CB5 Overall operation (Close + Open)

Erase

See § Commands

(By the interface program "MSCom2" it is possible to individually reset the counters and set an initial starting number)

TOTAL COUNTERS

Counters of the total number of operation of each individual function. These counters cannot be reset

T>	Thermal Image
1I>	First overcurrent element
2I>	Second overcurrent element
3I>	Third overcurrent element
4I>	Fourth overcurrent element
Iis	Instantaneous overcurrent
1dI	First current step element
2dI	Second current step element
1di/dt	First current rate of rise element
2di/dt	Second current rate of rise element
Rapp	Impedance monitoring (di/dt dependence)
Iapp	Current monitoring with di/dt dependence
1Ig	First Frame Fault element
2Ig	Second Frame Fault element
RS-G	Cable insulation (Screen-Ground)
RCL	Automatic Reclosure
1U>	First Overvoltage element
2U>	Second Overvoltage element
1U<	First Undervoltage element
2U<	Second Undervoltage element
Ni	Trip number arcs interrupts operations
Ne	Trip number electrical contact operations
Nm	Trip number mechanical operations of circuit breaker
Wi	Circuit Breaker maintenance alarm
TCS	Trip Circuit Supervision
IRF	Internal Relay Fault
RT	First Remote Trip
RTX	Second Remote Trip
BrkF	Breaker failure to open
SelfTrip	Spontaneous protection
AutOp	Automatic C/B Open
AutCL	Automatic C/B Close
ManOp	Manual C/B Open
ManCL	Manual C/B Close
OvrOp	Overall C/B Open (Automatic + Manual)
OvrCL	Overall C/B Close (Automatic + Manual)
LT	Automatic Line Test
DiaCB1	CB1 Input position discrepancy
AnCB1	CB1 Operation failure
OpCB1	CB1 Openings operation
CICB1	CB1 Closures operation
OprCB1	CB1 Overall operation (Close + Open)
DiaCB2	CB2 Input position discrepancy
AnCB2	CB2 Operation failure
OpCB2	CB2 Openings operation
CICB2	CB2 Closures operation
OprCB2	CB2 Overall operation (Close + Open)
DiaCB3	CB3 Input position discrepancy
AnCB3	CB3 Operation failure
OpCB3	CB3 Openings operation
CICB3	CB3 Closures operation
OprCB3	CB3 Overall operation (Close + Open)
DiaCB4	CB4 Input position discrepancy
AnCB4	CB4 Operation failure
OpCB4	CB4 Openings operation
CICB4	CB4 Closures operation
OprCB4	CB4 Overall operation (Close + Open)
DiaCB5	CB5 Input position discrepancy
AnCB5	CB5 Operation failure
OpCB5	CB5 Openings operation
CICB5	CB5 Closures operation
OprCB5	CB5 Overall operation (Close + Open)

Erase

See § Commands

(By the interface program "MSCom2" it is possible to individually reset the counters and set an initial starting number)

EVENTS

Function which caused any of the following events: - *Status change of digital Inputs/Outputs*. - *Start of protection functions – Trip of protection function* – *Function reset – system information*.

The last 500 events are always available on local – remote MMI interface (display or remote communication).

The memory buffer is refreshed at each new relay event (FIFO logic).

Each event is also stored on internal / external disk without limits (except the disk capacity)

Erase → See § Commands

Events

Functions	Events Displayed	Events Description MScom2	Status
T>	Tal T>	Tal (Alarm – Thermal Image T>) T> (Trip – Thermal Image T>)	Rise
1I>	1I> t1I>	1I> (Start - Fist overcurrent element F50-51) 1I> (Trip - Fist overcurrent element F50-51)	Rise Rise
2I>	2I> t2I>	2I> (Start – Second overcurrent element F50-51) 2I> (Trip – Second overcurrent element F50-51)	Rise Rise
3I>	3I> t3I>	3I> (Start – Third overcurrent element F50-51) 3I> (Trip - Third overcurrent element F50-51)	Rise Rise
4I>	4I> t4I>	4I> (Start - Fourth overcurrent element F50-51) 4I> (Trip - Fourth overcurrent element F50-51)	Rise Rise
Iis	Iis	Iis (Trip - Instantaneous overcurrent)	
1dI	1dI t1dI	1dI (Start - First Current Step Element) 1dI (Trip - First Current Step Element)	Rise Rise
2dI	2dI t2dI	2dI (Start - Second Current Step Element) 2dI (Trip - Second Current Step Element)	Rise Rise
1di/dt	1di/dt t1di/dt	1di/dt (Start - First Current Rate of Rise Element) 1di/dt Trip - (First Current Rate of Rise Element)	Rise Rise
2di/dt	2di/dt t2di/dt	2di/dt (Start - Second Current Rate of Rise Element) 2di/dt (Trip - Second Current Rate of Rise Element)	Rise Rise
Rapp	Rapp	Rapp (Trip - Impedance monitoring-di/dt dependence)	Rise
Iapp	Iapp	Iapp (Trip - Current monitoring-di/dt dependence)	Rise
1Ig	1Ig t1Ig	1Ig (Start - First Frame Fault Element) t1Ig (Trip - First Frame Fault Element)	Rise Rise
2Ig	2Ig t2Ig	2Ig (Start - Second Frame Fault Element) t2Ig (Trip - Second Frame Fault Element)	Rise Rise
RCL	RCLcmd ARP ARF ARL	RCL (Autoreclosure shot) ARP (Autoreclosure in Progress) ARF (Autoreclosure Failed) ARL (Autoreclosure Lockout)	Rise Rise Rise Rise
LT	LTcmd	LT (Line Test Command)	Rise
1U>	1U> t1U>	1U> (Start - First Overvoltage Element F59) 1U> (Trip - First Overvoltage Element F59)	Rise Rise
2U>	2U> t2U>	2U> (Start - Second Overvoltage Element F59) 2U> (Trip - Second Overvoltage Element F59)	Rise Rise
1U<	1U< t1U<	1U< (Start - First Undervoltage Element F59) t1U< (Trip - First Undervoltage Element F59)	Rise Rise
2U<	2U< t2U<	2U< (Start - Second Undervoltage Element F59) t2U< (Trip - Second Undervoltage Element F59)	Rise Rise
Wi	tWi> Ni alNi Ne alNe Nm alNm	Circuit breaker maintenance level Maximum number of arc chute operation at nominal values Alarm maintenance level of arc chute operation Maximum number of arc contact operation at nominal values Alarm maintenance level of arc contact operation Maximum number of mechanical operation Alarm maintenance level of mechanical operation	Rise
TCS	TCS tTCS	TCS (Start - trip coil supervision) tTCS (trip coil supervision)	Rise Rise
IRF	IRF tIRF	IRF (Start - Internal Relay Failure) tIRF (Trip - Internal Relay Failure)	Rise Rise
RT	Start RT Trip RT	RT (Start - First element Remote Trip) tRT (Trip - First element Remote Trip)	Rise Rise
RTX	Start RTX	RTX (Second element Remote Trip)	Rise

	Trip RTX	<i>tRTX (Trip - Second element Remote Trip)</i>	Rise
BF	BF	<i>BF (Breaker Failure)</i>	Rise
SelfTrip	SelfTrip	Spontaneous trip	Fall
	t-SelfTr.	Self-Trip time delay	
L/R CB Hdl	cmdOpC/B	<i>Circuit Breaker (CB) intentional open</i>	Rise
	cmdCIC/B	<i>Circuit Breaker (CB) intentional close</i>	Rise
	LocRemInc	<i>Local Remote inconsistent</i>	Rise
LT	LTPb	Output to operate an external flashing lamp signalling line test in progress	Rise
	LTP	Line Test in progress	Rise
	LTF	Line Test Failed	Rise
	LTOK	Line Test OK	Rise
	LTB	Line Test Blocked	Rise
	LT cmd	Line Test command	Rise

SYSTEMS (SYSTEM PARAMETERS)

Setting of system parameters.

System Parameters

System Rated Current	In	4000	A	(1 ÷ 9999)	step	1	A
System Rated Voltage	Un	1000	V	(100 ÷ 10000)	step	10	V
System Rated Ground Current	Ign	1000	A	(1 ÷ 9999)	step	1	A
System Rated Ground Voltage	Ugn	1000	V	(100 ÷ 10000)	step	10	V
Line Test resistance	Rtest	1	ohm	(1 ÷ 500)	step	1	ohm

Configuration Expansions

UX-10-4 Input modules Number	2	(0 -2)
14DI Input modules Number	0	(0 -2)
14DO Input modules Number	0	(0 -2)

General Comunication parameters

Node Address	1	(1÷250)	step	1
Password	1111	(1111÷9999)	step	1
SetUp Group	1	(1/2/3/4)		
Date				

Ethernet Comunication parameters

IP Address Mode	0.0.0.0	Static IP / Dynamic IP / DHCP
IPv4 address	0.0.0.0	STD Ethernet
IPv4 Subnet Mask Address	0.0.0.0	STD Ethernet
IPv4 Gateway Address	0.0.0.0	STD Ethernet
IPv4 NTP server1 Address	0.0.0.0	-
IPv4 NTP server2 Address	0.0.0.0	-
IPv4 NTP server3 Address	0.0.0.0	-
Host Name	xxxxxx	-

Information parameters

Protection Description	
IPU version	
IAU version	
Serial Number	

Input channel characteristics

DSPiChFact	10	(2÷10)	step	1
currR	0÷20	mA	(0÷20 / 4÷20 / 12÷20)	
currC	single		(single / dual)	
ADSEL	Analog		(Analog / Digital)	
pwmCard	1		(0 / 1)	
fibIP	Direct		(Direct / Invert)	
fibVP	Direct		(Direct / Invert)	
stI>ifBlk	Signal Disable		(Enable / Disable)	

Description of variables

DSPiChFact	: Ratio from first current analog channel and second analog channel (external transducer properties).
currR	: Input characteristic of first and second current analog channel (external transducer properties).
currC	: Single or dual channel external analog transducer (if single the second channel is not activated).
AdSel	: Analog or digital source for Current (I) and voltage (Vm), digital source is provided directly on fiber optic inputs from MHIT Microlettr4ica transducers; The others channels (Vv, Ig, Ug) continue to work in analog mode.
fibIP	: Digital current (I) measure direct or inverted (polarity).
fibVP	: Digital voltage (Vm) measure direct or inverted (polarity).
stI>ifBlk	: If enable Overcurrent instantaneous element are permanently locked when programmed block input is activated; If disable Overcurrent instantaneous element are delayed for [tBF] seconds when programmed block input is activated;

SETTINGS

Four complete banks of settings of the programmable variables are available in the "**SETTING**" menu.
Both "Characteristic-1" and "-2; -3; -4" include the hereunder listed variables.

HMI	Visualization parameters
USB	USB properties.
IP Protocols	Internet protocol properties.
IEC850 Protocol	IEC61850 protocol settings.
Modbus TCP Protocol	Modbus on TCP protocol properties.
NTP	Time date synchronization settings
Time Zone/DayLight	Time zone settings.
File system and Disk management	File system an disk management.
T>	Thermal Image
1I>	First overcurrent Element
2I>	Second overcurrent Element
3I>	Third overcurrent Element
4I>	Fourth overcurrent Element
Iis	Instantaneous overcurrent
1dI	First current step element
2dI	Second current step element
1di/dt	First current rate of rise element
2di/dt	Second current rate of rise element
Rapp	Impedance monitoring - di/dt dependence
Iapp	Current monitoring with di/dt dependence
1Ig	First Frame Fault element
2Ig	Second Frame Fault element
RCL	Automatic Reclosure
1U>	First Overvoltage Element
2U>	Second Overvoltage Element
1U<	First Undervoltage Element
2U<	Second Undervoltage Element
UL<	Line voltage presence
Wi	Amount of Energy to reach the C/B maintenance level
TCS	Setting variables for Trip Circuit Supervision
IRF	Internal Relay Fault
RT	First Remote Trip
RTX	Second Remote Trip
BrkFail	Setting variables for Breaker Failure detection
Dia-I	Diagnostic analog input currents
Wh	Energy counter Pulse
SelfTrip	Spontaneous trip
Oscillo	Setting variables for Oscillographic recording
L/R CB Cmds	C/B command Local / Remote setting
CB-L	Locks C/B reclosure
LT	Line Test
ExtResCfg	Configuration for external reset input
Dia C/B	Diagnostic C/B, switches position and statistic
Auxiliary C/B	Auxiliary C/B remote commands

Password

The password is requested any time the user wishes to modify any password protected parameter
(example "1I>" menu "Setting").

The factory default password is "**1111**".

The password is only modifiable with "MSCom2" software (see Manual "MSCom2").

Menu: Comm. (Serial Communication protocols options)

Options	→ BRRem	19200	[9600 / 19200 / 38400]
	→ PRRem	Modbus	[Modbus / IEC103]

Description of variables

BRRem	:	RS485 remote (Rear terminal block) serial communication speed
PRRem	:	Remote communication protocol:
<i>Modbus</i>	=	Modbus RTU
<i>IEC103</i>	=	IEC 103

USB port (mini-USB port on main unit)

A Mini-USB socket is available on Relay's main unit for composite connection.

CDC service serial interface connection:

Program available from Microelettrica Scientifica S.p.A. (MSCom2 for Windows XP/Vista/7) – it is possible connect a Personal Computer to download all available information's, operate any control and program the relay; the protocol used is "**MODBUS RTU**".


MSD service interface connection:

Direct access on internal and external disk of the unit to manage files and records.

This port is also used for FW upgrade of the main unit.

Cable for connection from Relay to Personal Computer

The connection cable is a standard
USB-A /mini USB-B



Rear serial communication port (RS485)

On the Relay's back terminal board, a RS485 ports is available for communication with SCADA system with Protocol Modbus RTU or IEC60870-5-103.

The communication interface allows programming all settings, operating all commands and downloading all information and records. The physical connection can be via a normal pair of wires (RS485) or, on request, via fiber optic.

Rear communication port (Ethernet)


Three Ethernet connection is available for communication on the Relay's back.

The Ethernet connector is a standard RJ45 and can be connected to a PC with a Ethernet "Cross" cable, or it can be connected to a switch with a Ethernet "Patch" cable.

These ports have simultaneous multi-protocol functionality (each communication protocol is always available on each port).

- Modbus On TCP
- IEC61850
- Internet protocol IPV4
- UDP (Network device discover Service server).
- TELNET (Remote protection Monitor server).
- FTP Protocol (File transfer server).
- NTP protocol (Network time protocol client).
- HTTP protocol (web server).

Wiring the Ethernet Communication



The back Ethernet connector is a standard RJ45 connector and can be wired with a normal Ethernet UTP cable in class 5 minimum.

The relay can be connected directly to a PC with a Ethernet "Cross" cable, or it can be connected to a switch with a Ethernet "Patch" cable.

Color Standard EIA/TIA T568A		Ethernet Patch Cable	
		RJ45 Pin#	Pin# RJ45
TX+	Green/White Tracer	1 Green/White Tracer	1 Green/White Tracer
TX-	Green	2 Green	2 Green
RX+	Orange/White Tracer	3 Orange/White Tracer	3 Orange/White Tracer
	Blue	4 Blue	4 Blue
RX-	Blue/White Tracer	5 Blue/White Tracer	5 Blue/White Tracer
	Orange	6 Orange	6 Orange
TX+	Brown/White Tracer	7 Brown/White Tracer	7 Brown/White Tracer
TX-	Brown	8 Brown	8 Brown



Color Standard EIA/TIA T568A		Ethernet Crossover Cable	
		RJ45 Pin#	Pin# RJ45
TX+	Green/White Tracer	1 Green/White Tracer	1 Orange/White Tracer
TX-	Green	2 Orange	2 Orange
RX+	Orange/White Tracer	3 Green/White Tracer	3 Green/White Tracer
	Blue	4 Brown/White Tracer	4 Brown/White Tracer
RX-	Blue/White Tracer	5 Brown	5 Brown
	Orange	6 Green	6 Green
TX+	Brown/White Tracer	7 Blue	7 Blue
TX-	Brown	8 Blue/White Tracer	8 Blue/White Tracer

"A" is earlier

Menu: HMI (Human Machine Interface)**Leds (Number)**

In this configuration, you can select the number of led (10 led STD on remote MMI).

Leds	→	10	[10 / 17 / 24 / 31 / 38 / 45 / 52 / 59]
-------------	---	----	---

Leds : Configuration Leds number

WirCB scheme – Scheme configuration


In this configuration, you can select the scheme that appears on the Home page (Remote Unit).

Wir	→	Scheme 1	[Scheme 1 / Scheme 2 / Scheme 3 / Scheme 4 / Scheme 5]
------------	---	----------	---


Wir : Circuit Breaker wiring selector

Scheme types


SCHEME 1




SCHEME 2




SCHEME 3



SCHEME 4




SCHEME 5




Example – Configuration with MScom2 software

Open "MSCom2" program and connect to the relay.

Select "CHANGE WINDOWS" from "Menu" button



Select "FUNCTION SETTING"



Select "HMI" function



Select "CIRCUIT BREAKER WIRING SELECTOR"



And select scheme



Configuration – Close Braker

In this configuration, you can select the Main (C/B) in the sheme selected

C/B	→ C/B1	Main C/B
	→ C/B2	Disconnector
	→ C/B3	Disconnector
	→ C/B4	Absent
	→ C/B5	Absent

*Load Break / Disconnector / Earthing switch
High speed Earthing switch /
Main C/B (Circuit breaker) / Absent*

USB

USB	→ USB-Device	CDC/MSD (Composite)
	→ USB-Host	Stick disk 4GB (or less)

IP Protocols

IP	→ IPV4	Mode/address
	→ UPD	Srv port: xxxx
	→ TELNET Protocol	Srv port: xxxx
	→ FTP Pptocol	Srv port: xxxx
	→ NTP Protocol	Max server x
	→ HTTP Protocol	Port: xx

IPV4	: Internet Protocol
UPD	: Network Device Discover Service Server
TELNET Protocol	: Remote Protection Monitor Server
FTP Pptocol	: File Transfer Server
NTP Protocol	: Network Time Protocol Client
HTTP Protocol	: Web Server

IEC61850 Protocol

IEC61850	→ IEC61850	Protocol Disable
	→ IEC61850	Warnings + Error

IEC61850	:	Type: <i>Protocol Disable</i> (acquired at start-up) <i>Protocol Enable</i> (acquired at start-up)
IEC61850	:	Log Level (info class stored on internal HD): <i>Only info</i> <i>Only warnings</i> <i>Only errors</i> <i>Warnings + errors</i> <i>Info + Warnings + errors</i> <i>Disable</i>

Modbus TCP Protocol

Modbus-TCP	→ Modbus-TCP (Server)	Srv port: xxx ; max connection: x
-------------------	------------------------------	-----------------------------------

NTP (Time/Date synchronization parameters)

NTP	→ Enab	Enable	[Enable/Disable]	min	step	1	min
	→ tSNTP	60	[1 ÷ 3600]				

Enab	: Enable date and time synchronization
tSNTP	: Periodic synchronization time

Time Zone/DayLight (Options)

NTP	→ GMT	GMT+1.00h	min	step	1	min
	→ SumT	Europe				
	→ toffs	0				

GMT	: Time Zone
SumT	: Isummer Time
toffs	: Synchronizing time offset, added if summer time is disable

File system and disks management
File System

→ updIAU	External disk
→ Log	Protection log file on internal disk
→ OniDF	Write Disable
→ OneDF	Write Disable
→ FTPvo	Internal disk

updIAU	:	IAU (Intelligent acquisition unit) FW update source: <i>Disabled : No IAU FW update procedure activated on PWR ON.</i> <i>External disk (USB stick): FW update enabled from USB stick</i> <i>Internal disk:) FW update enabled from USB stick</i>
Log	:	Enable log files: <i>Protection log file disabled</i> <i>Protection log file on internal disk</i> <i>Protection log file on external disk</i>
OniDF	:	Write policy on internal full disk condition: <i>Write disable</i> <i>Delete older folder and write</i>
OneDF	:	Write policy on external full disk condition: <i>Write disable</i>
FTPvo	:	FTP exported volume: <i>Internal disk</i> <i>External disk (USB stick)</i> <i>Both disks</i>

Function: T> (Thermal Image F49)
Status

→ Enab.	Disable	[Disable / Enable]
----------------	---------	--------------------

Levels

→ Tal	50	%Tn	[10 ÷ 100]	step	1	%Tn
→ Tres	50	%Tb	[10 ÷ 100]	step	1	%Tb
→ Is	1	In	[0.5 ÷ 1.5]	step	0.01	In
→ Kt	300	min	[1 ÷ 600]	step	0.01	min

Description of variables
Status

Function enabling (Disable / Enable)

Tal

Temperature prealarm level

Tres

Temperature reset (drop-off temperature)

Is

Continuous admissible current

Kt

Warming-up Time Constant of the load

Trip and Alarm

The algorithm compares the amount of heat accumulated "T" ($\equiv I^2 \cdot t$) to the steady state amount of heat "Ts" corresponding to continuous operation at the continuously admissible current "Is".

When the ratio "T/Ts" reaches the level set for Thermal Alarm "Tal" of the max allowed heating, the relay trips accordingly, and remain in trip condition until the temperature "T" is over the reset temperature "Tres".


Trip time of the Thermal Image Element

The trip time of the Thermal Image Element is a function of the current "I" flowing into the load and depends on its warming-up Time Constant "Kt", on the previous thermal status "Ip" and on the maximum admissible continuous current "Is" according to the equation:

t	=	Time to relay tripping
Kt	=	Load thermal time constant
I	=	Actual load current
In	=	Load rated current
Is	=	Continuous admissible current
Ip	=	Steady state current before the overload
ln	=	Natural Logarithm

$$t = Kt \cdot \ell_n \frac{\left(\frac{I}{In}\right)^2 - \left(\frac{Ip}{In}\right)^2}{\left(\frac{I}{In}\right)^2 - \left(\frac{Is}{In}\right)^2}$$

When the heating exceeds the set alarm level "Tal" or the max. allowed level ("I" > "Is" for the time "t") the output relays programmed for these function will be operated. Reset will take place when the heating will drop below 95% of the trip level.

Thermal Image Curves (TU1024 Rev.1)

Function: 1I> (First Overcurrent Element F50/51)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ f(t)	Type - D	[D / A / B / C]
	→ tBI	Disable	[Disable / 2tBO]
	→ f(a)	Fw	[Disable / Fw / Rev]
	→ RCL	No	[No / Yes]
Levels	→ Is	1	In (0.1÷4) step 0.01 In
Timers	→ ts	100	s (0.01÷100) step 0.01 s
	→ tBO	0.75	s (0.05÷0.75) step 0.01 s

Description of variables

Status	: Function enabling (Disable / Enable)
f(t)	: Operation characteristic (Time/Current curve): (D) = Independent definite time (A) = IEC Inverse Curve type A (B) = IEC Very Inverse Curve type B (C) = IEC Extremely Inverse Curve type C
tBI	: Blocking input reset time: Disable = Permanent block 2tBO = Set 2xtBO.
f(a)	: Operation mode: Disable = Non Directional Fw = Directional Forward Rev = Directional Reverse
RCL	: If "RCL = Yes", after tripping of the element "1I>" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
Is	: Minimum operation level
ts	: Trip time delay
tBO	: Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

Algorithm of the time current curves

The Time Current Curves are generally calculated with the following equation

$$(1) \quad t(I) = \left[\frac{A}{\left(\frac{I}{I_s} \right)^a - 1} + B \right] \cdot K \cdot T_s + T_r \quad \text{where}$$

$t(I)$ = Actual trip time delay when the input current equals "I"
 I_s = Set minimum pick-up level

$$K = \left(\frac{A}{10^a - 1} + B \right)^{-1}$$

T_s = Set time delay: $t(I) = T_s$ when $\frac{I}{I_s} = 10$

t_r = Operation time of the output relay on pick- up.

The parameters A, B and a have different values for the different Time Current Curves.

Curve Name	Curve Identifier	A	B	a
IEC A Inverse	A	0.14	0	0.02
IEC B Very Inverse	B	13.5	0	1
IEC C Extremely Inverse	C	80	0	2

For the IEC curves, being $B = 0$, the Time/Current equation (1), becomes:


$$(1') \quad t(I) = \frac{(10^a - 1)T_s}{\left(\frac{I}{I_s} \right)^a - 1} + t_r = \frac{Kt}{\left(\frac{I}{I_s} \right)^a - 1} + t_r$$

Where $Kt = (10^a - 1)T_s$ is the time multiplier

When " $f(t) = D$ " is programmed, the trip time delay is Definite and independent from the current excess " $t = ts$ ".

The maximum measuring current is "40xIn" for phase elements and "10xOn" for the neutral elements.

Trip takes place when the current measured exceeds (no matter how much) the set level " I_s " for the set time " ts ".

IEC Curves


Curve Type	A	B	K	a
IEC A	0.14	0	0.336632	0.02
IEC B	13.5	0	0.666667	1
IEC C	80	0	1.2375	2

Max. "I" Phase = $40 \times In$
Max. "I" Neutral = $10 \times On$

Blocking Logic (BO-BI)

For each Protection Function it is possible to activate a Blocking Logic allowing for inhibiting their operation by external signals supplied to the Digital Input.

Output Blocking signal "BO"

All the protection functions that can be programmed to operate in the blocking logic mode, element, have an instantaneous element (beside the time delayed) which is operated as soon as the controlled quantity exceeds the set trip level ($I > [Is]$ for current, etc..) and is instantaneously reset when the input quantity drops below the reset level (normally 0.95Is).

The instantaneous element can control one of the user programmable output relays that, by its contacts, makes the signal available for blocking an external element (BO = Blocking Output).

In case, "tBO" sec after the set trip time "ts" has expired, the Protection function is still in operation (current above trip level), the Blocking Output relay (instantaneous element) is anyhow reset to eventually remove the Blocking signal from a back-up protection.

Blocking Input "BI"

For all the functions controllable by the Blocking Logic, it is possible to inhibit the time delayed tripping by an external signal that activates a Digital Input programmed for this functionality.

The programmed Digital Input gets activated by an external cold contact closing across its terminals.

With the variable "tBI" set to "OFF" (tBI=OFF), the tripping of the delayed function is blocked as long as the Blocking Input signal is present at the terminals of the Digital Input.

With the variable "tBI" set to "2xtBI" (tBI=2xtBI), 2xtBI seconds after the set trip time delay of the function has expired the blocking input is anyhow ignored and the function enabled to trip.

Automatic doubling of Overcurrent thresholds on current inrush

For some of the phase Overcurrent functions it is possible to have the set trip level [Is] automatically doubled when strong inrush current is detected.

If at circuit Breaker switch-on (i.e. when the input current rises from zero to a minimum measurable value) the current increases from 0 to 1.5 times the rated value [In] in less than 60ms, the set minimum pick-up level [Is] is dynamically doubled ([Is]→[2Is]) and keeps this value until the input current drops below 1.25xIn or the set time [t2xI] has elapsed.

This functionality is very useful to avoid spurious tripping of the instantaneous, or short-time delayed Overcurrent elements, that could be experienced at switch-on when energizing the feeder.

Function: 2I> (Second Overcurrent Element F50/51)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ f(t)	Type - D	[D / A / B / C]
	→ tBI	Disable	[Disable / 2tBO]
	→ f(a)	Disable	[Disable / Fw / Rev]
	→ RCL	No	[No / Yes]
Levels	→ Is	1	In (0.1÷4) step 0.01 In
Timers	→ ts	100	s (0.01÷100) step 0.01 s
	→ tBO	0.75	s (0.05÷0.75) step 0.01 s

Description of variables

Status	: Function enabling (Disable / Enable)
f(t)	: Operation characteristic (Time/Current curve): (D) = Independent definite time (A) = IEC Inverse Curve type A (B) = IEC Very Inverse Curve type B (C) = IEC Extremely Inverse Curve type C
tBI	: Blocking input reset time <i>Disable</i> = Permanent block <i>2tBO</i> = Set 2xtBO.
f(a)	: Operation mode: <i>Disable</i> = Non Directional <i>Fw</i> = Directional Forward <i>Rev</i> = Directional Reverse
RCL	: If "RCL = Yes", after tripping of the element "2I>" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
Is	: Minimum operation level
ts	: Trip time delay
tBO	: Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

Function: 3I> (Third Overcurrent Element F50/51)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ tBI	Disable	[Disable / 2tBO]
	→ f(a)	Disable	[Disable / Fw / Rev]
	→ CoF	Disable	[Disable / Enable]
	→ RCL	No	[No / Yes]
Levels	→ Is	1	In (0.1÷10) step 0.01 In
Timers	→ ts	100	s (0.01÷100) step 0.01 s
	→ tCoF	0.05	s (0.02÷0.2) step 0.01 s
	→ tBO	0.75	s (0.05÷0.75) step 0.01 s

Description of variables

Status	:	Function enabling (Disable / Enable)
tBI	:	Blocking input reset time <i>Disable</i> = Permanent block <i>2tBO</i> = Set 2xtBO.
f(a)	:	Operation mode: <i>Disable</i> = Non Directional <i>Fw</i> = Directional Forward <i>Rev</i> = Directional Reverse
CoF	:	If "CoF = Enable", any time the circuit breakers status changes from open to close the "3I>" element is enabled to trip instantaneously if the current exceeds the set value "Is" within the time "tCoF". (Close On Fault Function)
RCL	:	If "RCL = Yes", after tripping of the element "3I>" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
Is	:	Minimum operation level.
ts	:	Trip time delay
tCoF	:	Maximum duration of the Close on Fault function.
tBO	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

Function: 4I> (Fourth Overcurrent Element F50/51)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ tBI	Disable	[Disable / 2tBO]
	→ f(a)	Disable	[Disable / Fw / Rev]
	→ CoF	Disable	[Disable / Enable]
	→ RCL	No	[No / Yes]
Levels	→ Is	10	In (0.1÷10) step 0.01 In
Timers	→ ts	100	s (0.01÷100) step 0.01 s
	→ tCoF	0.05	s (0.02÷0.2) step 0.01 s
	→ tBO	0.75	s (0.02÷0.2) step 0.01 s

Description of variables

Disable	:	Function enabling (Disable / Enable)
tBI	:	Blocking input reset time <i>Disable</i> = Permanent block <i>2tBO</i> = Set 2xtBO.
f(a)	:	Operation mode: <i>Disable</i> = Non Directional <i>Fw</i> = Directional Forward <i>Rev</i> = Directional Reverse
CoF	:	If "CoF = Enable", any time the circuit breakers status changes from open to close the "3I>" element is enabled to trip instantaneously if the current exceeds the set value "Is" within the time "tCoF". (Close On Fault Function)
RCL	:	If "RCL = Yes", after tripping of the element "4I>" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
Is	:	Minimum operation level.
ts	:	Trip time delay
tCoF	:	Maximum duration of the Close on Fault function.
tBO	:	Time to reset of the Blocking Output after expiring of the Trip time delay. "tBO" is also the trip time delay of the Breaker Failure function.

Function: *Iis* (Instantaneous Current Element)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ RCL	No	[No / Yes]
Levels	→ Iis	1	In (1÷10) step 0.1 In

Description of variables

Disable	:	Function enabling (Disable / Enable)
RCL	:	If "RCL = Yes", after tripping of the element "Iis" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
f(a)	:	Operation mode: <i>Disable</i> = Non Directional <i>Fw</i> = Directional Forward <i>Rev</i> = Directional Reverse
Iis	:	Minimum operation level.

Function: *1delta-I* (First Current Step Element)

Status	→ Enab.	Disable	[Disable / Enable]	
Options	→ RCL	No	[No / Yes]	
Levels	→ DI	1000	A (100÷9990) → di 200 A/ms (4÷400)	step 10 A step 1 A/ms
Timers	→ tDI	100	ms (0÷500) → tdi 20 ms (0÷100)	step 1 ms step 1 ms

Description of variables


Status	:	Function enabling (Disable / Enable)
RCL	:	If "RCL = Yes", after tripping of the element "1di" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
DI	:	Current step trip level
di	:	Minimum di/dt level to start " ΔI " evaluation and detection reset level
tDI	:	Trip time delay
tdi	:	Detection reset time delay

Operation of the Current step monitoring element

The timely detection of a current step allow to clear a near short circuit long before the current can reach the prospective peak value.

Protection Function Operation (see Fig. 1):

- Any time a current rate of rise exceeding the set value [di] is detected the value of the current "i_{1b}" is recorded as reference basic value to evaluate the current step " $\Delta I = i - i_{1b}$ " and the timer "tDI" is started. " ΔI " is evaluated every 1ms.
- If during [tDI] the rate of rise "di/dt" never goes below the set level [di] for a time longer than [tdi], when [tDI] expires, the difference $\Delta I = i - i_{1b}$ is measured and if " $\Delta I \geq [DI]$ " the protection function trips.
- If during [tDI] the rate of rise "di/dt" goes below the set level [di] for a time longer than [tdi], a new value of the current i_{2b} is recorded and, when [tDI] expires. If the difference $\Delta I = i - i_{2b}$ measured is greater than [DI], the protection function trips.


Fig.1

In terms of equation the protection function operation is as follow:

$$\text{If } \frac{di}{dt} \geq [di] \Rightarrow \begin{cases} \text{Value of Current } i_{1b} \text{ is recorded} \\ \text{Timer tDI is Started} \end{cases} \Rightarrow \text{If During tDI} \Rightarrow$$

$$\Rightarrow \begin{cases} \frac{di}{dt} \geq [di] \text{ during tdi} \Rightarrow \text{Trip if } \Delta = i - i_{1b} \geq [DI] \text{ after tDI} \\ \frac{di}{dt} < [di] \text{ during tdi} \Rightarrow \text{New Value of Current } i_{2b} \text{ is recorded} \Rightarrow \text{Trip if } \Delta = i - i_{2b} \geq [DI] \text{ after tDI} \end{cases}$$

If, at the end of [tDI] no trip occurs " ΔI " evaluation is stopped and will restart when the set "di/dt" level is exceeded.

Function: 2delta-I (Second Current Step Element)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ RCL	No	[No / Yes]
Levels	→ DI	1000	A (100÷9990)
	→ di	200	A/ms (4÷400)
Timers	→ tDI	100	step 10 A
	→ tdi	20	step 1 A/ms

Description of variables

Disable	: Function enabling (Disable / Enable)
RCL	: If "RCL = Yes", after tripping of the element "2dI" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
DI	: Current step trip level
di	: Minimum di/dt level to start " ΔI " evaluation and detection reset level
tDI	: Trip time delay
tdi	: Detection reset time delay

Function: 1di/dt (First Current Rate of Rise Element)

Status	→ Enab.	Disable	[Disable / Enable]						
Options	→ RCL	No	[No / Yes]						
Levels	→ G	20	A/ms (4÷400)	step	1	A/ms			
Timers	→ tG	20	ms (2÷500) → tRes	0	ms (0÷500)	step	1	ms	ms

Description parameters

Disable	:	Function enabling (Disable / Enable)
RCL	:	If "RCL = Yes", after tripping of the element "1di/dt" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
G	:	di/dt trip level
tG	:	Trip time delay
tRes	:	Reset time delay

Operation of the current rate of rise monitoring element

This function is used to detect remote faults

Current is sampled at 5kHz, is measured as the average of 15 samples are stored in a buffer from which every 1ms the relay computes the average rate of rise in the set time delay:

$$\frac{di}{dt} = \frac{I_{(t+tG)} - I_{(t)}}{tG}$$

if $\frac{di}{dt} \geq [G]$ the relay trip

Function: 2di/dt (Second Current Rate of Rise Element)

Status	→ Disable			Disable / Enable]
Options	→ RCL	No	[No / Yes]	
Levels	→ G	20	A/ms	(4÷400) step 1 A/ms
Timers	→ tG	20	ms	(2÷500) step 1 ms
	→ tRes	0	ms	(0÷500) step 1 ms

Description parameters

Status	:	Function enabling (No = Disable / Yes = Enable)
RCL	:	If "RCL = Yes", after tripping of the element "1di/dt" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
G	:	di/dt trip level
tG	:	Trip time delay
tRes	:	Reset time delay

Operation of the current rate of rise monitoring element

This function is used to detect remote faults

Current is sampled at 5kHz, is measured as the average of 15 samples and stored in a buffer from which every 1ms the relay computes the average rate of rise in the set time delay:

$$\frac{di}{dt} = \frac{I_{(t+[tG])} - I_{(t)}}{tG}$$

if $\frac{di}{dt} \geq [G]$ the relay trip

Function: Rapp (Impedance monitoring - di/dt dependence)

Status	→ Enab.	Disable	[Disable / Enable]				
Options	→ RCL	No	[No / Yes]				
Levels	→ Va	400	V	(0÷800)	step	1	V
	→ Ri	0.1	Ω	(0÷0.25)	step	0.001	Ω
	→ Rt	1	Ω	(0.001÷2.5)	step	0.001	Ω
	→ Li	0.005	H	(0.001÷0.01)	step	0.001	H
	→ Lt	0.01	H	(0.002÷0.05)	step	0.001	H
	→ R*	50	Ω	(0÷100)	step	0.01	Ω
	→ g	50	A/ms	(10÷500)	step	1	A/ms
Timers	→ tr	50	ms	(0÷100)	step	1	ms

Description of variables


Status	:	Function enabling (Disable / Enable)
RCL	:	I If "RCL = Yes", after tripping of the element "Rapp" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
Va	:	Arc voltage.
Ri	:	Internal Resistance = Resistance of the circuit upstream the Circuit Breaker.
Rt	:	Total resistance of the circuit including the Contact Line.
Li	:	Internal Inductance = Inductance of the circuit upstream the Circuit Breaker.
Lt	:	Total Inductance of the circuit including the Contact Line.
R*	:	Resistance trip level if $di/dt \geq g$.
g	:	Limit value of di/dt .
tr	:	Trip time delay.

Operation the Impedance monitoring element

The protection element shall trip if the impedance "Rapp" calculated as the ratio of the line voltage to the line current drops below the calculated value with the current rate of rise exceeding the level as reported on the trip characteristics. Trip takes place if the situation lasts longer than the set time delay "tr".

$$Rapp = \left[V - \frac{Ri(V - Va)}{Rt} + \left(\frac{Lt}{Rt} \cdot Ri - Li \right) g \right] : \left(\frac{V - Va}{Rt} - \frac{Lt}{Rt} \cdot g \right)$$

Reset takes place when "Rapp" is 10% higher than the trip value.



Function: Iapp (Current monitoring with di/dt dependence)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ RCL	No	[No / Yes]
Levels	→ IA	1500	A (500÷5000)
	→ I*	500	A (400÷1500)
	→ g	50	A/ms (30÷500)
	→ Res	90	% (80÷100)
Timers	→ tr	0.1	s (0÷5)
			step 10 A
			step 10 A
			step 1 A/ms
			step 1 %Iapp
			step 0.01 s

Description of variables

Disable	:	Function enabling (Disable / Enable)
RCL	:	If "RCL = Yes", after tripping of the element "Iapp" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
IA	:	Current trip level when $di/dt = 0$
I*	:	Current trip level when $di/dt \geq [g]$
g	:	Limit value of di/dt
Res	:	Drop-out percentage (operation reset)
tr	:	Trip time delay.


Operation of the "Iapp" element

The protection shall trip if current measured exceeds the value $[Iapp]$ calculated as hereunder showed for longer than the set time "tr" reset takes place as soon as the current drops below

$$[Iapp] \cdot \frac{Res}{100}$$

$$Iapp = -\left[\frac{IA - I^*}{g}\right] \cdot \frac{di}{dt} - [IA] \quad \text{if } 0 \leq \frac{di}{dt} \leq g$$

$$Iapp = I^* \text{ if } \frac{di}{dt} > g$$



Function: 1Ig (First Frame Fault Element)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ f(t)	Type - D	[D / A / B / C]
	→ V(t)	Type - D	[D / EN]
	→ RCL	No	[No / Yes]
Levels	→ Is	1	Ign (0.00÷2) Ugn (0.00÷1)
	→ Us	0.2	step 0.01 Ign step 0.01 Ugn
Timers	→ ts	20	s (0.02÷100)
			step 0.01 s

Description of variables

Status	: Function enabling (Disable / Enable)
f(t)	: Operation characteristic (Time/Current curve): (D) = Independent definite time (A) = IEC Inverse Curve type A (B) = IEC Very Inverse Curve type B (C) = IEC Extremely Inverse Curve type C
V(t)	: Operation characteristic (Time/Current curve): (D) = Independent definite time (EN50122-1) = Inverse Curve
RCL	: If "RCL = Yes", after tripping of the element "1Ig" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
Is	: Minimum operation level of frame to earth current.
Us	: Minimum operation level of frame to earth voltage.
ts	: Trip time delay

Operation

Trip takes places if, for larger than the set time delay [ts], both the ground fault current "Ig" and the Voltage to ground "Ug" exceed the set values [Is] and [Us].

If "Is = 0" the relay shall consider "Ug" only, viceversa if "Ug = 0" the relay shall consider "Ig" only.

Setting		Tripping condition
Is	Us	
≠0	≠0	Ig>[Is] & Ug>[Us]
≠0	=0	Ig>[Is]
=0	≠0	Ug>[Us]

Function: 2Ig (Second Frame Fault Element)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ f(t)	Type - D	[D / A / B / C]
	→ V(t)	Type - D	[D / EN]
	→ RCL	No	[No / Yes]
Levels	→ Is	1	Ign (0.00÷2) Ugn (0.00÷1)
	→ Us	0.2	step 0.01 Ign step 0.01 Ugn
Timers	→ ts	20	s (0.02÷100)
			step 0.01 s

Description of variables

Status	:	Function enabling (Disable / Enable)
f(t)	:	Operation characteristic (Time/Current curve): (D) = Independent definite time (A) = IEC Inverse Curve type A (B) = IEC Very Inverse Curve type B (C) = IEC Extremely Inverse Curve type C
V(t)	:	Operation characteristic (Time/Current curve): (D) = Independent definite time (EN50122-1) = Inverse Curve
RCL	:	If "RCL = Yes", after tripping of the element "2Ig" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
Is	:	Minimum operation level of frame to earth current.
Us	:	Minimum operation level of frame to earth voltage.
ts	:	Trip time delay

Operation

Trip take place if, for larger than the set time delay [ts], both the ground fault current "Ig" and the Voltage to ground "Ug" exceed the set values [Is] and [Us].

If "Is = 0" the relay shall consider "Ug" only viceversa if "Ug = 0" the relay shall consider "Ig" only.

Is	Setting		Tripping condition
	Us		
≠0	≠0	Ig>[Is] & Ug>[Us]	
≠0	=0	Ig>[Is]	
=0	≠0	Ug>[Us]	

Function: RCL (Automatic Reclosure)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ ShNum	2	[1 / 2 / 3 / 4]
	→ Test	Yes	[No / Yes]
Timers	→ tr	10	s (1÷200)
	→ t1	0.3	s (0.1÷1000)
	→ t2	1	s (0.1÷1000)
	→ t3	3	s (0.1÷1000)
	→ t4	10	s (0.1÷1000)
	→ tCHK	0.4	s (0.2÷3)
	→ tCHRT	100	s (1÷600)

Description of variables

Status	:	Function enabling (Disable / Enable)
ShNum	:	Number of reclosure shots to Lock-out
Test	:	"Yes" - Before any reclosure the Line Test is started and the reclosure is operated only after a successful Line Test is carried-out. "No" - Reclosure is operated without Line-Test.
tr	:	Reclaim time. Any new trip during "tr" after a successful reclosure shot starts the next shot of the cycle. Any new trip after "tr" restarts a complete cycle.
tCHK	:	Time check C/B operation if any protection function trip except RT/RTX; if one or more protection elements doesn't reset before "tCHK" expire the RCL goes into Lock status.
tCHRT	:	Time check C/B operation if RT/RTX Trip; If RT/RTX doesn't reset before "tCHRT" expire the RCL goes into Lock status.

Operation

The status of the Circuit Breaker (C/B) is indicated by one normally open contact of the C/B itself and is detected by a digital input of the relay.

A reclose shot is started after a C/B's opening operated by one of the relay's protection functions programmed to control this reclose shot; C/B's opening operated by one element not programmed to control the reclosure shot activates the Lock-out status of the Reclosure function.

Any time the Circuit Breaker (C/B) is closed either manually or automatically the Reclaim time "tr" is started.

After a manual closure of the C/B, operation time start or tripping of any of the relay protection elements during "tr", makes the relay enter into the Lock-Out status (L.O.). In the L.O. status the relay, after breaker opening, does not produce any command for automatic reclose ; the lock-out status is shows on the display.

Reset from the L.O. status takes place when the C/B is opened and then manually reclosed or by operating the external reset command.

If none of the relay protection elements is started during "tr" after a manual closure of the C/B, the relay is ready to start the Automatic Reclose Sequence.

If "tr" is started by an automatic reclosure, the operation time start during "tr" and the tripping of any element programmed for the operation of the next reclosure makes the relay proceed with the reclosing cycle.

After "tr" is expired the reclosing cycle restarts from the first reclosure (1C).

Pick-up of the time start of any protection element, stops the counting down of "tr"; counting is restarted as soon as the element resets.

As soon as the C/B is opened due to tripping of one of the relay's elements programmed to initiate the next automatic reclose shot, the relevant reclose time delay (t1, t2, t3, t4) is started and at the end of this tx time the reclose command is issued by the relay. The C/B is then automatically reclosed and the reclaim time "tr" is started again. If during "tr" the C/B is again opened by a relay's element programmed to initiate the next automatic reclose, the next reclose takes place after the relevant time tx; the C/B is reclosed and "tr" restarted. When the last Automatic Reclose shot of the sequence has been done, any further tripping during "tr" produces a relay's lock-out status. If after any reclose shot no tripping takes place during "tr", the Reclose Sequence is restarted from the beginning (starting from the first reclose shot 1C)

Function: 1U> (First OverVoltage Element F59)

Status	→ Enab.	Disable	[Disable / Enable]			
Levels	→ Us	1.10	Un	(0.5÷1.50)	step	0.01
Timers	→ ts	10	s	(0÷650)	step	1

Description of variables

Status	:	Function enabling (Disable / Enable)
Us	:	Minimum operation level
ts	:	Trip time delay

Function: 2U> (Second OverVoltage Element F59)

Status	→ Enab.	Disable	[Disable / Enable]			
Levels	→ Us	1.10	Un	(0.5÷1.50)	step	0.01
Timers	→ ts	10	s	(0÷650)	step	1

Description of variables

Status	:	Function enabling (Disable / Enable)
Us	:	Minimum operation level
ts	:	Trip time delay

Function: 1U< (First UnderVoltage Element F27)

Status	→ Enab.	Disable	[Disable / Enable]			
Levels	→ Us	0.70	Un	(0.05÷1)	step	0.01
Timers	→ ts	10	s	(0÷650)	step	1

Description of variables

Status	:	Function enabling (Disable / Enable)
Us	:	Minimum operation level
ts	:	Trip time delay

Function: 2U< (Second UnderVoltage Element F27)

Status	→ Enab.	Disable	[Disable / Enable]			
Levels	→ Us	0.70	Un (0.05÷1)	step	0.01	Un
Timers	→ ts	10	s (0÷650)	step	1	s

Description of variables
Status : Function enabling (Disable / Enable)

Us : Minimum operation level

ts : Trip time delay

Function: UL< (Line Voltage Presence)

Status	→ Enab.	Disable	[Disable / Enable]			
Levels	→ UL<int	0.9	Un (0.05÷1.50)	step	0.01	Un
	→ UL<Ric	1.1	Un (0.05÷1.50)	step	0.01	Un
Timers	→ tUL<	0.2	s (0.2÷200)	step	1	s

Description of variables
Status : Function enabling (Disable / Enable)

UL<int : Minimum operation pickup level

UL<Ric : Minimum operation dropoff level

tUL< : Trip time delay

Function: Wi (Circuit Breaker maintenance level)

Status	→ Enab.	Disable	[Disable / Enable]			
Levels	→ Ni	1.000				
	→ alNi	80	%	(10÷1000)	step	1
	→ Ne	1.000		(5÷95)	step	1
	→ alNe	80	%	(10÷99999)	step	1
	→ Nm	1.000		(5÷95)	step	1
	→ alNm	900	%	(10÷99999)	step	1
	→ Ii	3.000	A	(100÷9999)	step	1
Timers	→ ti	20	ms	(10÷40)	step	1
	→ tr	8	ms	(0÷50)	step	1

Description of variables

Disable	:	Function enabling (Disable / Enable)
Ni	:	Maximum number of arc chute operation at nominal values
alNi	:	Alarm maintenance level of arc chute operation
Ne	:	Maximum number of arc contact operation at nominal values
alNe	:	Alarm maintenance level of arc contact operation
Nm	:	Maximum number of mechanical operation
alNm	:	Alarm maintenance level of mechanical operation
Ii	:	Circuit Breaker Rated Current primary amps.
ti	:	HSCB open time
tr	:	HSCB auxiliary contact delay

Operation (Accumulation of the interruption Energy)

The relay computes the Circuit Breaker interruption Energy.

On the relay is possible to set the total level of energy that the breaker is able to interrupt.

During each C/B operation the remain energy is calculated.

The operation of this function is based on the following principle:

Arc chute:

Any time the Circuit Breaker opens, the relay accumulate the square value of the current measured from the instance of the circuit breaker opening to the instant when the current expire.

The opening instant is detected by the change of status from closed to open of digital input connected to normally open contact of the C/B; it is compensated by the parameter "tr":

$$Ei = \sum_{0}^{n} [i^2]$$

The value calculated is subtracted from the amount total energy available calculated with the following formula:

$$Ei_{(total)} = Ii^2 * ti * Ni$$

"Ni" is the number of operation that the arc chute can done at the nominal values of C/B (current, and interrupting time).

On the measures menu is available the remaining energy value calculated as follow:

$$\frac{Ei\%}{Ei_{(total)}} = \frac{Ei}{Ei_{(total)}} * 100$$

When the remaining energy value goes below the **AlNi** threshold an alarm is generated .

When the remaining energy value decreased to **zero** another alarm is generated.

The generated alarm can be "linked" to digital outputs (relays) or used in programmable logic functions.

Reset to **100%** of the Energy accumulation is available in the menu "**Command**" (Reset Ei).

Arc contact:

Any time the Circuit Breaker opens, the relay record the value of the current measured at the instance of the circuit breaker opening. The opening instant is detected by the change of status from closed to open of digital input connected to normally open contact of the C/B; it is compensated by the parameter "tr":

$$\mathbf{Ee} = [i^2]$$

The value calculated is subtracted from the amount total energy available calculated with the following formula:

$$\mathbf{Ee(\text{total})} = \mathbf{Ii^2 * Ne}$$

"**Ne**" is the number of operation that the arc contact can done at the nominal values of C/B (current).

On the measures menu is available the remaining energy value calculated as follow:

$$\mathbf{Ee\%} = \frac{\mathbf{Ee(\text{total})} - \mathbf{Ee}}{\mathbf{Ee (\text{total})}} * 100$$

When the remaining energy value goes below the **AINe** threshold an alarm is generated .

When the remaining energy value decreased to **zero** another alarm is generated.

The generated alarm can be "linked" to digital outputs (relays) or used in programmable logic functions.

Reset to **100%** of the Energy accumulation is available in the menu "**Command**" (Reset Ee).

Mechanical operations:

Any time the Circuit Breaker opens, the relay compute the mechanical operation (opening and closing).

When the mechanical operations counter [**OVrOP**] value exceed the **AINm** threshold an alarm is generated .

When the mechanical operations counter [**OVrOP**] value exceed the **Nm** threshold another alarm is generated .

The generated alarm can be "linked" to digital outputs (relays) or used in programmable logic functions.

Reset of the mechanical operation is available in the menu "**Command**" (Reset Counters).

Function: TCS (Trip Circuit Supervision)

Status	→ Enab.	Disable	[Disable / Enable]
Timers	→ ts	0.1	s (0.1÷100) step 0.01 s

Description of variables

Status	:	Function enabling (Disable / Enable)
ts	:	Trip time delay

Operation

The relay includes a complete Circuit Breaker Trip Circuit Supervision unit that is associated to the Contact "19-20" of the "R1" Output Relay. The contact of "R1" is used to trip the C/B as reported in the drawing here below.

The supervision works when the C/B is closed and recognizes the Trip Circuit as sound as far as the current flowing exceeds "1mA".


In case of Trip Circuit Fault detection, the diagnostic relay is operated and the Led starts flashing (see § Signalization).

To have Supervision also with the C/B open one N/C contact (52b) from the C/B and an external resistor "R" are needed.

$$R[k\Omega] \leq \frac{V}{1mA} - R_{52} \quad \text{where } R_{52} = \text{Trip Coil internal resistance [k}\Omega]$$

V = Trip Circuit Voltage

$$P_R \geq 2 \cdot \frac{V^2}{R} [W] \quad \text{Designed power of external resistance "R"}$$



Tripping of the function operates a user programmable output relay.

Function: IRF (Internal Relay Fault)

In this menu it is possible to configurate the operation of the Relay Internal Fault detection element

Status	→ Enab.	Disable	[Disable / Enable]
Timers	→ tIRF	5.00	s (5÷200) step 0.01 s

Description of variables

Status	:	Function enabling (No = Disable / Yes = Enable)
tIRF	:	Trip time delay

Operation

Tripping of the function operates a user programmable output relay.

Function: RT (First Element Remote Trip)

In this menu it is possible to configurate the Remote Trip Element.

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ RCL	No	[No / Yes]
	→ RTon	FallEdge	[RiseEdge – FallEdge]
Timers	→ ts	5	s (0 ÷ 10) step 0.01 s

Description of variables

Status	:	Function enabling (Disable / Enable)
RCL	:	If "RCL = Yes", after tripping of the element "RT" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
RTon	:	Remote trip Edge selector
ts	:	Trip time delay

Operation

Tripping of the function operates a user programmable output relay.

When Remote Trip is enabled to initiate a reclosure shot, the relevant input signal must be cleared within the time-out "to1" (1000ms); if the signal stays for longer than "to1" the reclosure function goes into the lock-out status giving an External Fail signal.

Function: RTX (Second Element Remote Trip)

In this menu it is possible to configurate the Remote Trip Element.

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ RCL	No	[No / Yes] [RiseEdge – FallEdge]
Timers	→ ts	5 s	(0 ÷ 10) step 0.01 s

Description of variables

Status	:	Function enabling (Disable / Enable)
RCL	:	If "RCL = Yes", after tripping of the element "RTX" and Opening of the Circuit Breaker, the relay starts an automatic Line Test and a reclosure cycle. If "RCL = No" no test and no reclosure is started.
RTon	:	Remote trip Edge selector
ts	:	Trip time delay

Operation

Tripping of the function operates a user programmable output relay.

When Remote Trip is enabled to initiate a reclosure shot, the relevant input signal must be cleared within the time-out "to1" (1000ms); if the signal stays for longer than "to1" the reclosure function goes into the lock-out status giving an External Fail signal.

Function: BrKFail (Breaker Failure)

Status	→ Enab.	Disable	[Disable / Enable]
Timers	→ tBF	0.75 s	(0.05÷0.75) step 0.01 s

Description of variables

Status	:	Function enabling (Disable / Enable)
tBF	:	Trip time delay

Operation

The Breaker Failure detection is started by the operation of the output relay "R1" (programmed to be controlled by the Protection Functions that trip the C/B).

If after [tBF] seconds from operation of the relay "R1", any input current flow is still detected (>10% In), the function "BF" trips and operate one user programmable output relay,

Function: Dia-I (Diagnostic analog inputs current)

Status	→ Enab.	Disable	[Disable / Enable]
Timers	→ tDiaI	60	s (1÷180) step 1 s

Description of variables

Status	:	Function enabling (Disable / Enable)
tDiaI	:	Time delay current measurement channel failure

Operation

Tripping of the function operates a user programmable output relay.
Function dedicated to transducers with zero live (4-20mA , 12-20mA); if the reading current value goes to zero .

- If the reading current goes to zero for a time longer than [tDiaI], the protection function trips.

Function: Wh (Energy counter Pulse)

In this menu it is possible to configurate the Energy counter Pulse.

Status	→ Enab.	Disable	[Disable / Enable]
Levels	→ WpP	100	kW (10 ÷ 1000) step 10 kW
Timers	→ Pulse	1	s (0.1 ÷ 2) step 0.01 s

Description of variables

Disable	:	Function enabling (Disable / Enable)
WpP	:	Energy counter Pulse Level
Pulse	:	Pulse duration

Operation

One selected output relay issued a pulse from an external energy counter, each pulse corresponds to the programmed Energy unit "WpP" and its duration is the set time "Pulse".

Function: Self Trip (Spontaneous trip)

In this menu it is possible to configure the Self Trip function.

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ RCL	No	[No / Yes]
Timers	→ ts	5	s (0 ÷ 10) step 0.01 s

Description of variables

Disable	:	Function enabling (Disable / Enable)
RCL	:	Reclosure
ts	:	Self-Trip time delay

Operation

This function is use to individuate the "CB self-trip" without make any complex logic with "user variables".
The function check only the "Main HSCB", and if it pass from close status to open, without a command issued by the relay, the "self-trip" variable is set.

Function: Oscillo (Oscillographic Recording)

Status	→ Enab.	Disable	[Disable / Enable]
Options	→ Trig	Start	[Start / Trip / OnCmd / REUserLg / FEUserLG]
Timers	→ tPre	0.50	s (0.01÷2) step 0.01 s
	→ tPost	0.50	s (0.01÷8) step 0.01 s

Description of variables

Disable	:	Function enabling (Disable / Enable)
Trig	:	Selection of the Trigger command source (start recording):
		<i>Start</i> = Trigger on time start of protection functions
		<i>Trip</i> = Trigger on trip (time delay end) of protection functions
		<i>OnCmd</i> = On Asynchronous Force trigger command
		<i>REUserLg</i> = On rising edge of "User Logic"
		<i>FEUserLg</i> = On falling edge of "User Logic" (see § "OscilloTriggerLogic")
tPre	:	Recording time before Trigger
tPost	:	Recording time after Trigger

Operation

In the options: "Trig = Start" and "Trig = Trip", the oscillographic recording starts respectively when any protection function starts operating or trip (provided the function was programmed "TrigEnab").

T>	1I>	1dI	Rapp	Wi	1U>
	2I>	2dI	Iapp	RT	2U>
	3I>	1di/dt	1Ig	RTX	1U<
	4I>	2di/dt	2Ig		2U<

In the option "ExtInp", the oscillographic record starts when the Digital Input is activated (terminals shorted)

The "Osc" Function includes the wave Form Capture of the input quantities (I, U, Ig, Ug).

The waveforms of the oscillographic recording are always available for direct access (communication) on the memory of the relay, the maximum record time available for direct access is 40 seconds.

The number of events recorded depends on the duration of each individual recording (tPre + tPost).

In any case the number of event stored can not exceed ten (10 x 0.6 sec).

Any new event beyond the 40 sec capacity of the memory, cancels and overwrites the former records (FIFO Memory).

Example: "10x4s" or "5x8s" etc.

Each oscillographic record is also stored in COMTRADE format on internal/external disk;

There is no limit to the records stored on disk (except the disk space), the length of each event, in any case, is maximum 10 seconds.

Available on MSCom2

T>	Tal T>	(alarm) (trip)	<i>Thermal element</i>
1I>	1I> t1I>	(Start) (Trip)	<i>First overcurrent element</i>
2I>	2I> t2I>	(Start) (Trip)	<i>Second overcurrent element</i>
3I>	3I> t3I>	(Start) (Trip)	<i>Third overcurrent element</i>
4I>	4I> t4I>	(Start) (Trip)	<i>Fourth overcurrent element</i>
Iis	tIis>	(Start)	<i>Instantaneous Current Element</i>
1dI	1dI t1dI	(Start) (Trip)	<i>First Current step element</i>
2dI	2dI t2dI	(Start) (Trip)	<i>Second Current step element</i>
1di/dt	1di/dt t1di/dt	(Start) (Trip)	<i>First Current rate of rise element</i>
2di/dt	2di/dt t2di/dt	(Start) (Trip)	<i>Second Current rate of rise element</i>
Rapp	Rapp	(Trip)	<i>Impedance monitoring – di/dt dependence</i>
Iapp	Iapp		<i>Current monitoring with di/dt dependence</i>
1Ig	1Ig t1Ig	(Start) (Trip)	<i>First instantaneous Frame Fault element</i> <i>First time delayed Frame Fault element</i>
2Ig	2Ig t2Ig	(Start) (Trip)	<i>Second Frame Fault element</i>
RCL	RCL cmd ARP ARF ARL AROk ARE ARD	(Trip)	<i>Reclosure Shot command</i> <i>Autoreclosure in progress</i> <i>Autoreclosure Failure</i> <i>Autoreclosure Lock-out</i> <i>Autoreclosure Ok</i> <i>Autoreclosure Enable</i> <i>Autoreclosure Disable</i>
1U>	1U> t1U>	(Start) (Trip)	<i>First overvoltage element</i>
2U>	2U> t2U>	(Start) (Trip)	<i>Second overvoltage element</i>
1U<	1U< t1U<	(Start) (Trip)	<i>First undervoltage element</i>
2U<	2U< t2U<	(Start) (Trip)	<i>Second undervoltage element</i>
UL<	UL<		<i>Line Voltage presence</i>
Wi	Ni alNi Ne alNe Nm alNm		<i>Maximum number of arc chute operation at nominal values</i> <i>Alarm maintenance level of arc chute operation</i> <i>Maximum number of arc contact operation at nominal values</i> <i>Alarm maintenance level of arc contact operation</i> <i>Maximum number of mechanical operation</i> <i>Alarm maintenance level of mechanical operation</i>
TCS	tTCS	(Trip)	<i>Time delayed Trip Circuit Supervision</i>
IRF	IRF tIRF	(Start) (Trip)	<i>Time delayed Internal relay Fault</i> <i>Instantaneous Internal relay Fault</i>
RT	RT tRT	(Trip) (Start)	<i>First Instantaneous Remote Trip</i> <i>First Time delayed Remote Trip</i>
RTX	RTX tRTX	(Trip) (Start)	<i>Second Instantaneous Remote Trip</i> <i>Second Time delayed Remote Trip</i>
Dia-I	Dial tDial	(Trip) (Start)	<i>Diagnostic analog inputs current</i> <i>Delay current measurement channel failure</i>
CB-L	CB-L		<i>C/B reclose Lock-out</i>
BF	BF		<i>Breaker Failure</i>
Wh	+ Wh - Wh		<i>Exported Energy counter Pulse</i> <i>Imported Energy counter Pulse</i>
SelfTrip	SelfTrip t-SelfTr.		<i>Spontaneous trip</i> <i>Self-Trip time delay</i>
L/R CB Hdl	cmdOpCB cmdClCB LocRemInc missCBOpe		<i>Open C/B command</i> <i>Close C/B command</i> <i>Local / Remote Inconsistency</i> <i>Missed C/B opening (Digital input missing)</i>
Characteristics	Charat 1 Charat 2 Charat 3 Charat 4		<i>Characteristic 1</i> <i>Characteristic 2</i> <i>Characteristic 3</i> <i>Characteristic 4</i>
LT	LTPb LTP LTF LTOK LTB LT cmd	(Trip)	<i>Output to operate an external flashing lamp signalling line test in progress</i> <i>Line Test in progress</i> <i>Line Test Failed</i> <i>Line Test OK</i> <i>Line Test Blocked</i> <i>Line Test command</i>

I850Ready	<i>IEC61850 ready to work.</i>
Sync	<i>Date – time synchronization event (active during clock synchronization).</i>
SNTP-Dia	<i>SNTP health status.</i>
SNTP-Kod	<i>Syncro lost by server, Kiss of death. Date-Time need syncro from another server.</i>
DskClean	<i>External Disk Clean (disk near to full, clean operation is required)</i>
DskFull	<i>External Disk Full (disk full, write should be locked)</i>
DskWr	<i>External Disk Write (active during internal disk access)</i>
DskFRMT	<i>External Disk Format (active during internal disk format)</i>
DskCHK	<i>External Disk Check (active during internal disk check procedure)</i>
rDskAttach	<i>Remote disk inserted (USB Key)</i>
rDskDetach	<i>Remote disk not inserted (USB Key)</i>
rDskDtchable	<i>Remote disk removable (USB Key)</i>
rDskClean	<i>External Disk Clean (disk near to full, clean operation is required)</i>
rDskFull	<i>External Disk Full (disk full, write should be locked)</i>
rDskWr	<i>External Disk Write (active during internal disk access)</i>
rDskFRMT	<i>External Disk Format (active during internal disk format)</i>
rDskCHK	<i>External Disk Check (active during internal disk check procedure)</i>
CB1Fail	<i>CB1 Failure</i>
CB2Fail	<i>CB2 Failure</i>
CB3Fail	<i>CB3 Failure</i>
CB4Fail	<i>CB4 Failure</i>
CB5Fail	<i>CB5 Failure</i>
CB1missedOp	<i>CB1 Failure</i>
CB2missedOp	<i>CB2 Failure</i>
CB3missedOp	<i>CB3 Failure</i>
CB4missedOp	<i>CB4 Failure</i>
CB5missedOp	<i>CB5 Failure</i>
MasterOp1	<i>Modbus Master CB1 Open request</i>
MasterCL1	<i>Modbus Master CB1 Close request</i>
MasterOp2	<i>Modbus Master CB2 Open request</i>
MasterCL2	<i>Modbus Master CB2 Close request</i>
MasterOp3	<i>Modbus Master CB3 Open request</i>
MasterCL3	<i>Modbus Master CB3 Close request</i>
MasterOp4	<i>Modbus Master CB4 Open request</i>
MasterCL4	<i>Modbus Master CB4 Close request</i>
MasterOp5	<i>Modbus Master CB5 Open request</i>
MasterCL5	<i>Modbus Master CB5 Close request</i>
Gen.Start	<i>General start</i>
Gen.Trip	<i>General Trip</i>
Vcc	<i>Reserved</i>
Gnd	<i>Reserved</i>
ResLog	<i>Reset signal logic</i>
P1	<i>Push-button Open (Not used with remote MMI)</i>
P2	<i>Push-button Close (Not used with remote MMI)</i>
P3	<i>Push-button Reset (Not used with remote MMI)</i>
UserTriggerOscillo	<i>User Variable for Oscillographic Recording</i>
UserVar<0>	
to	<i>User Variable</i>
UserVar<98>	

Only for "DIGITAL INPUT"

0.D1	<i>Digital Input "0.D1"</i>	<i>activated</i>
0.D1Not	<i>Digital Input "0.D1"</i>	<i>deactivated</i>
to		
0.D4	<i>Digital Input "0.D4"</i>	<i>activated</i>
0.D4Not	<i>Digital Input "0.D4"</i>	<i>deactivated</i>
1.D1	<i>Digital Input "1.D1"</i>	<i>activated</i>
1.D1Not	<i>Digital Input "1.D1"</i>	<i>deactivated</i>
to		
1.D15	<i>Digital Input "1.D15"</i>	<i>activated</i>
1.D15Not	<i>Digital Input "1.D15"</i>	<i>deactivated</i>
2.D1	<i>Digital Input "2.D1"</i>	<i>activated</i>
2.D1Not	<i>Digital Input "2.D1"</i>	<i>deactivated</i>
to		
2.D15	<i>Digital Input "2.D15"</i>	<i>activated</i>
2.D15Not	<i>Digital Input "2.D15"</i>	<i>deactivated</i>

Setting "Oscillo Trigger Logic"

The "**OSCILLO TRIGGER LOGIC**" is a result of a logical operation (Or, AND, ecc...), it can be used like other logical output. This operation is possible only via "MSCom2" software.

Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Logical status
------	-------------	------------------	---------	-------	------------	----------------

Name

Internal name

User descr.

Fixed

Linked functions

Selection functions

OpLogic

Operation Logic = [None, OR, AND, XOR, NOR, NAND, NOT, Ff-SR]

Timer

Time delay (0-10)s, step 0.01s

Timer type

Timer	=	<i>Delay</i>	:	Add a delay on output activation. The "Timer" is edge triggered on rise edge.
		<i>Monostable P</i>	:	Monostable Positive pulse time
		<i>Monostable N</i>	:	Monostable Negative pulse time
		<i>Blinking</i>	:	When selected output is a 50% duty cycle square wave
		<i>Delay Fall-Down</i>	:	Time added on falling output edge


Logical status

"OscilloTriggerLogic" Logical status


Example: Setting "User Variable"

Open "MSCom2" program and connect to the relay.

Select "Change Windows" from "Menu" button




Select "User Variable"

Setting for "User Trigger Oscillo" : "**1I>/2I>/3I>**", "**AND**", "**1**", "**Monostable P**".



ID	Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Logical status
1	UserTrigger Oscillo	OscilloTrigger.logic		None	0	Delay	0
2	UserVar <0>	Gate.1.....		None	0	Delay	0
3	User Variables		None	0	Delay	0

“Linked Functions”

Select “**Linked Functions**” related to “User Trigger Oscillo” and press right button on mouse, select “Value change”:




Select “**1I>, 2I>, 3I>**” from “Available” box via push-button “<Add”, and press “OK”.
For remove functions, use push-button “>Remove”.




“Operation Logic” (Oplogic)

Select “**Oper Logic**” related to “User Trigger Oscillo” and press right button on mouse, select “Value change”:




Insert “**AND**” into box and press “OK”:



“Timer”


Select “**Timer**” related to “User Trigger Oscillo” and press right button on mouse, select “Value change”:

Select “**1**” into box and press “OK”:




“Timer type”

Select “**Timer**” related to “User Trigger Oscillo” and press right button on mouse, select “Value change”:



Select “**Monostable P**” into box and press “OK”:



Function: L/R CB Cmds (Local Remote Close Breaker Command)

This menu allows to configurate the command for C/B operation.

Options	→ LocRm	Disable	[Enable / Disable]
	→ DI_M	Remote	[Remote / Local]
	→ LineT	Disable	[Enable / Disable]
	→ Key	Enable	[Enable / Disable]
Timers	→ tLRIn	0.05	s (0.05 ÷ 1) step 0.05 s
	→ tOpen	1	s (0.05 ÷ 10) step 0.01 s

Description of variables

LocRm	:	Enable/Disable [Local/Remote] Digital input.
LineT	:	Line Test Enable/Disable If Enabled = Line Test will be started any time C/B Close control is activated.
DI_M	:	Local/Remote digital input management
Key	:	<i>Enable</i> = The C/B can be controlled by the pushbuttons available on Relay's Front Face as well as by commands sent via the serial communication bus. <i>Disable</i> = The pushbuttons on Front Panel are disabled; the operation of the C/B can be controlled either by the serial bus commands or by (password protected) commands available in the menu " Commands ".
tLRIn	:	Local/Remote inconsistent time.
tOpen	:	C/B operation time-out.

Function: CB-L (CB Lock)

This menu allows to configurate the command lock for C/B.

Options	→ Lock	Enable	[Enable / Disable]
Timers	→ tLTBk	1	s (0.1 ÷ 10) step 0.1 s

Description of variables

Lock	:	<i>Enable</i> = Enabling of the close command lock-out. <i>Disable</i> = Disabling of the close command lock-out.
tLTBk	:	Line Test progress blink time

Operation

If the variable "Lock" is set to "Enable", reclosing of the C/B is inhibited after a "Failed reclosure" or after a "Failed Line Test". The reset from the Lock-out status can be operated either by the keyboard via the "CB Unlock" command available in the menu "Commands" (§ Commands) or by an external command via the Digital Input programmed for "Ext.Reset".

Function: LT (Automatic Line Test)

Options	→ TNum	1	[0 / 1 / 2 / 3]
	→ Fast	No	[No / Yes]
	→ Rem	No	[No / Yes]
Levels	→ V/I	Voltage	(Voltage / Current)
	→ Vv<	0.5	Vn (0÷1)
	→ Vm<	0.5	Vn (0÷1)
	→ Vlock	0.05	Vn (0.05÷1)
	→ Rr<	100	Ω (0÷500)
	→ VFast	0.5	Vn (0.5÷1)
Timers	→ tp	3	s (0÷30)
	→ tt	3	s (0.1÷10)
	→ tcy	10	s (1÷180)
	→ t	3	s (0÷10)

Description of variables

TNum	:	Number of tests after an unsuccessful test.
Fast	:	Yes : When set to "YES" if the voltage measured during the set pre-closing time [tp] exceeds the set level [VFast], the C/B is closed immediately without the Line Test; If the voltage measured doesn't exceed the [Vfast] level and exceeds the set level [Vlock] the line test fail output and the C/B lock-out was performed; Finally if the line voltage drops below the set level [Vlock] normal line test with check of line resistance value is normally carried out.
STD	:	When set to "STD" if the voltage measured during the set pre-closing time [tp] exceeds the set level [VFast], the C/B is closed immediately without the Line Test.
MIN	:	When set to "MIN" if the voltage measured during the set pre-closing time [tp] drops below the set level [VFast] the line test fail output and the C/B lock-out was performed. Otherwise normal line test with check of line resistance value is normally carried out.
No	:	If set "No" test is normally carried out.
Rem	:	Remote line test; if "Yes" Line Test can be started by the logical output RCL
V/I	:	Current : Line resistance is calculated using Line Current and Line Voltage, in this case the algorithm don't use [Vv] measure. Voltage : Line resistance is calculated using the difference from [Vm] and [Vv] and the rated value "Rtest" (line test resistor value).
Vv<	:	Minimum downstream voltage level to allow C/B close
Vm<	:	Minimum upstream voltage level to allow C/B close
Vlock	:	Maximum line voltage to allow Line Test in Yes mode
Rr<	:	Minimum Residual Resistance level to allow C/B closing.
VFast	:	Minimum Line Voltage level to allow C/B closing without Line Test.
tp	:	Waiting time after C/B closing command request to start the line test cycle.
tt	:	Duration of the Line Test.
tcy	:	Wait time between two consecutive tests.
t	:	Wait time to start reclosing after success fine test.

Operation

The Line Test is started by a request of Automatic Reclosure or Manual Closure of the C/B (see § "RCL" and § "L/R C/B Cmds").

It is also possible to start the Line Test by activating a Digital Input programmed for this purpose (see § Remote Line Test control).

Voltage working:

Test is considered successful depending on "Vv<", "Vm<" and "Rr<" measurement according to programming.

Setting Vm<	Vv<	Rr<	Test condition
≠0	≠0	≠0	Vv ≥ [Vv<] & Vm ≥ [Vm<] & Rr ≥ [Rr<]
≠0	≠0	=0	Vv ≥ [Vv<] & Vm ≥ [Vm<]
=0	=0	≠0	Rr ≥ [Rr<]

If the test was unsuccessful:

If "Test N°=0"	C/B reclosing blocked
If "Test N°=1,2,3"	The timer "tcy" is started and, at the end of "tcy" the test is repeated only 1 or 2 or three times before the C/B reclosing is blocked (if one of the tests is successful, "tw" is started and then the C/B closed).


Current working:

Test is considered successful depending on "Vr<" and "Rr<" measurement according to programming.

Setting Vm<	Rr<	Test condition
≠0	≠0	Vr ≥ [Vr<] & Rr ≥ [Rr<]
≠0	=0	Vr ≥ [Vr<]
=0	≠0	Rr ≥ [Rr<]

If the test was unsuccessful:

If "Test N°=0"	C/B reclosing blocked
If "Test N°=1,2,3"	The timer "tcy" is started and, at the end of "tcy" the test is repeated only 1 or 2 or three times before the C/B reclosing is blocked (if one of the tests is successful, "tw" is started and then the C/B closed).

Flow chart


Function: ExtResCfg (External Reset Configuration)

This menu allows to select the edge polarity of the signal on the digital input configured to reset the relay after a trip.
The reset input will reset all the output relays configured as manual reset (latched), the signalisation of the trip on the display and the indication of the LED are cleared also.

Options	→ ActOn	RiseEdge	[RiseEdge / FallEdge]
----------------	----------------	----------	-----------------------

Description of variables

ActOn	:	<i>RiseEdge</i>	Active on Rise Edge (Digital Input close).
		<i>FallEdge</i>	Active on Fall Edge (Digital Input open).

Function: Dia C/B (Diagnostic C/B position)

In this menu it is possible to configure the CB incongruence function.

Status	→ Enab.	Disable	[Disable / Enable]
Timers	→ tCB1f	3	s (0 ÷ 10) step 0.1 s
	→ tCB1A	2	s (0 ÷ 10) step 0.1 s
	→ tCB2f	3	s (0 ÷ 10) step 0.1 s
	→ tCB2A	2	s (0 ÷ 10) step 0.1 s
	→ tCB3f	3	s (0 ÷ 10) step 0.1 s
	→ tCB3A	2	s (0 ÷ 10) step 0.1 s
	→ tCB4f	3	s (0 ÷ 10) step 0.1 s
	→ tCB4A	2	s (0 ÷ 10) step 0.1 s
	→ tCB5f	3	s (0 ÷ 10) step 0.1 s
	→ tCB5A	2	s (0 ÷ 10) step 0.1 s

Description of variables

tCB1f	:	C/B1 Diagnostic position discrepancy filter time
tCB1A	:	C/B1 operation control time
tCB2f	:	C/B2 Diagnostic position discrepancy filter time
tCB2A	:	C/B2 operation control time
tCB3f	:	C/B3 Diagnostic position discrepancy filter time
tCB3A	:	C/B3 operation control time
tCB4f	:	C/B4 Diagnostic position discrepancy filter time
tCB4A	:	C/B4 operation control time
tCB5f	:	C/B5 Diagnostic position discrepancy filter time
tCB5A	:	C/B5 operation control time

Operation

For each auxiliary CB is possible set the incongruence status of its auxiliary contact (1NO e 1 NC). In case the two contacts are in the same status (open are close) for a time longer then tCBxf, a variable (linkable) is set.

Function: auxRCmds (Auxiliary Remote Commands)

In this menu it is possible to configure timer for duration of command.

Timers	→	tCl1	1	s	(0÷10)	step	0.1	s
	→	tOp1	1	s	(0÷10)	step	0.1	s
	→	tCl2	1	s	(0÷10)	step	0.1	s
	→	tOp2	1	s	(0÷10)	step	0.1	s
	→	tCl3	1	s	(0÷10)	step	0.1	s
	→	tOp3	1	s	(0÷10)	step	0.1	s
	→	tCl4	1	s	(0÷10)	step	0.1	s
	→	tOp4	1	s	(0÷10)	step	0.1	s
	→	tCl5	1	s	(0÷10)	step	0.1	s
	→	tOp5	1	s	(0÷10)	step	0.1	s

Description of variables

tCl1	:	Master close breaker 1 command duration
tOp1	:	Master open breaker 1 command duration
tCl2	:	Master close breaker 2 command duration
tOp2	:	Master open breaker 2 command duration
tCl3	:	Master close breaker 3 command duration
tOp3	:	Master open breaker 3 command duration
tCl4	:	Master close breaker 4 command duration
tOp4	:	Master open breaker 4 command duration
tCl5	:	Master close breaker 5 command duration
tOp5	:	Master open breaker 5 command duration

INPUT – OUTPUT (VIA SOFTWARE MSCom2)

The firmware can manage up to 28 digital inputs and 24 output relays; among these, 4 digital inputs and 6 output relays are available on the relay module, the remaining are available on additional expansion modules controlled via the CAN-Bus communication channel:

14DI	Module	(Board 1)	=	14 Digital Inputs
14DO	Module	(Board 2)	=	14 Outputs Relay
UX10-4	Module	(Board 3)	=	10 Digital Inputs - 4 Outputs Relay

The interfacing software "MSCom2" also allows to program the operation of the output relays (Physical Output), and Digital Inputs (see MSCom2 Manual).

Digital Input

→ 0.D1	Programmable (D1)	When the relevant terminals are open and get activated when the relevant terminals are shorted by an external cold contact.	<i>Available in the relay This are self-powered.</i>
→ 0.D2	Programmable (D2)		
→ 0.D3	Programmable (D3)		
→ 0.D4	Programmable (D4)		
→ 1.D1	Inputs	<i>Digital input on Expansion Board 1</i>	
→ 1.D--	"D8", "D16" not available		
→ 1.D15			
→ 2.D1	Inputs	<i>Digital input on Expansion Board 2</i>	
→ 2.D--	"D8", "D16" not available		
→ 2.D15			

Three of them (0.D1, 0.D2, 0.D3) are deactivated, when the relevant terminals are open and get activated when the relevant terminals are shorted by an external cold contact.

The operation of the Input "0.D4" is dependent on the value "R" of resistance of the external circuit connected to its terminals (24-25/26):

- Activated if "R < 50Ω" or "R > 3000Ω". - Deactivated if "50Ω ≤ R ≤ 3000Ω".

Therefore, if the terminals "24-25/26" are open-circuited, the input "0.D4" is activated; for using "0.D4" as A normal Digital Input simply controlled by an external cold contact, it is necessary to permanently connect across the terminal's "24-25/26" (in parallel to the external contact) a load resistor of value between 50 and 3000Ω (example 1000Ω - 0.5W).

"DI" Configuration parameter available (via keyboard or MSCom2 software)

Any of the Digital Inputs can be programmed to control one or more of the following functions.

C/B1-Close	Close position status
C/B1-Open	Open position status
C/B1-I/D	Insertion status
C/B2-Close	Close position status
C/B2-Open	Open position status
C/B2-I/D	Insertion status
C/B3-Close	Close position status
C/B3-Open	Open position status
C/B3-I/D	Insertion status
C/B4-Close	Close position status
C/B4-Open	Open position status
C/B4-I/D	Insertion status
C/B5-Close	Close position status
C/B5-Open	Open position status
C/B5-I/D	Insertion status
Bi1I>	Blocking input to the 1I>
Bi2I>	Blocking input to the 2I>
Bi3I>	Blocking input to the 3I>
Bi4I>	Blocking input to the 4I>
BiRCL	Reclosure lock-out RCL
Bypass-LT	Line test bypass

Bi1U<	Blocking input to the 1U<
Bi2U<	Blocking input to the 2U<
Main C/B CL.Status	Circuit breaker status
RT	Remote Trip input
RTX	Second Remote Trip input
BiLT	Line Test blocking inputs
Bi1didt	Blocking input 1di/dt
Bi2didt	Blocking input 2di/dt
Local	Local mode operation
Remote	Remote mode operation
Open CB	Open C/B Command
Close CB	Close C/B Command
RemLT	Remote line test input
Ext Reset	External Reset input
BOpCB	Blocking input open CB
BCICB	Blocking input close CB
Group1	Setting Group 1
Group2	Setting Group 2
Group3	Setting Group 3
Group4	Setting Group 4

Function available

In this list are show the functions that can be associated with digital inputs or output relay.

T>	Tal T>	(alarm) (trip)	<i>Thermal element</i>
1I>	1I> t1I>	(Start) (Trip)	<i>First overcurrent element</i>
2I>	2I> t2I>	(Start) (Trip)	<i>Second overcurrent element</i>
3I>	3I> t3I>	(Start) (Trip)	<i>Third overcurrent element</i>
4I>	4I> t4I>	(Start) (Trip)	<i>Fourth overcurrent element</i>
Iis	tIis>	(Start)	<i>Instantaneous Current Element</i>
1dl	1dI t1dI	(Start) (Trip)	<i>First Current step element</i>
2dl	2dI t2dI	(Start) (Trip)	<i>Second Current step element</i>
1di/dt	1di/dt t1di/dt	(Start) (Trip)	<i>First Current rate of rise element</i>
2di/dt	2di/dt t2di/dt	(Start) (Trip)	<i>Second Current rate of rise element</i>
Rapp	Rapp	(Trip)	<i>Impedance monitoring – di/dt dependence</i>
Iapp	Iapp		<i>Current monitoring with di/dt dependence</i>
1Ig	1Ig t1Ig	(Start) (Trip)	<i>First instantaneous Frame Fault element</i> <i>First time delayed Frame Fault element</i>
2Ig	2Ig t2Ig	(Start) (Trip)	<i>Second Frame Fault element</i>
RCL	RCL cmd	(Trip)	<i>Reclosure Shot command</i> <i>Autoreclosure in progress</i> <i>Autoreclosure Failure</i> <i>Autoreclosure Lock-out</i> <i>Autoreclosure Ok</i> <i>Autoreclosure Enable</i> <i>Autoreclosure Disable</i>
1U>	1U> t1U>	(Start) (Trip)	<i>First overvoltage element</i>
2U>	2U> t2U>	(Start) (Trip)	<i>Second overvoltage element</i>
1U<	1U< t1U<	(Start) (Trip)	<i>First undervoltage element</i>
2U<	2U< t2U<	(Start) (Trip)	<i>Second undervoltage element</i>
UL<	UL<		<i>Line Voltage presence</i>
Wi	Ni aINi Ne aINe Nm aINm		<i>Maximum number of arc chute operation at nominal values</i> <i>Alarm maintenance level of arc chute operation</i> <i>Maximum number of arc contact operation at nominal values</i> <i>Alarm maintenance level of arc contact operation</i> <i>Maximum number of mechanical operation</i> <i>Alarm maintenance level of mechanical operation</i>
TCS	tTCS	(Trip)	<i>Time delayed Trip Circuit Supervision</i>
IRF	IRF	(Start)	<i>Time delayed Internal relay Fault</i>
	tIRF	(Trip)	<i>Instantaneous Internal relay Fault</i>
RT	RT tRT	(Trip) (Start)	<i>First Instantaneous Remote Trip</i> <i>First Time delayed Remote Trip</i>
RTX	RTX tRTX	(Trip) (Start)	<i>Second Instantaneous Remote Trip</i> <i>Second Time delayed Remote Trip</i>
Dia-I	Dial tDial	(Trip) (Start)	<i>Diagnostic analog inputs current</i> <i>Delay current measurement channel failure</i>
CB-L	CB-L		<i>C/B reclose Lock-out</i>
BF	BF		<i>Breaker Failure</i>
Wh	+ Wh - Wh		<i>Exported Energy counter Pulse</i> <i>Imported Energy counter Pulse</i>
SelfTrip	SelfTrip t-SelfTr.		<i>Spontaneous trip</i> <i>Self-Trip time delay</i>
L/R CB Hdl	cmdOpCB cmdCICB LocRemInc missCBOpe		<i>Open C/B command</i> <i>Close C/B command</i> <i>Local / Remote Inconsistency</i> <i>Missed C/B opening (Digital input missing)</i>
Characteristics	Charat 1 Charat 2 Charat 3 Charat 4		<i>Characteristic 1</i> <i>Characteristic 2</i> <i>Characteristic 3</i> <i>Characteristic 4</i>
LT	LTPb LTP LTF LTOK LTB LT cmd		<i>Output to operate an external flashing lamp signalling line test in progress</i> <i>Line Test in progress</i> <i>Line Test Failed</i> <i>Line Test OK</i> <i>Line Test Blocked</i> <i>Line Test command</i>

I850Ready	<i>IEC61850 ready to work.</i>
Sync	<i>Date – time synchronization event (active during clock synchronization).</i>
SNTP-Dia	<i>SNTP health status.</i>
SNTP-Kod	<i>Syncro lost by server, Kiss of death. Date-Time need syncro from another server.</i>
DskClean	<i>External Disk Clean (disk near to full, clean operation is required)</i>
DskFull	<i>External Disk Full (disk full, write should be locked)</i>
DskWr	<i>External Disk Write (active during internal disk access)</i>
DskFRMT	<i>External Disk Format (active during internal disk format)</i>
DskCHK	<i>External Disk Check (active during internal disk check procedure)</i>
rDskAttach	<i>Remote disk inserted (USB Key)</i>
rDskDetach	<i>Remote disk not inserted (USB Key)</i>
rDskDetchable	<i>Remote disk removable (USB Key)</i>
rDskClean	<i>External Disk Clean (disk near to full, clean operation is required)</i>
rDskFull	<i>External Disk Full (disk full, write should be locked)</i>
rDskWr	<i>External Disk Write (active during internal disk access)</i>
rDskFRMT	<i>External Disk Format (active during internal disk format)</i>
rDskCHK	<i>External Disk Check (active during internal disk check procedure)</i>
CB1Fail	<i>CB1 Failure</i>
CB2Fail	<i>CB2 Failure</i>
CB3Fail	<i>CB3 Failure</i>
CB4Fail	<i>CB4 Failure</i>
CB5Fail	<i>CB5 Failure</i>
CB1missedOp	<i>CB1 Failure</i>
CB2missedOp	<i>CB2 Failure</i>
CB3missedOp	<i>CB3 Failure</i>
CB4missedOp	<i>CB4 Failure</i>
CB5missedOp	<i>CB5 Failure</i>
MasterOp1	<i>Modbus Master CB1 Open request</i>
MasterCL1	<i>Modbus Master CB1 Close request</i>
MasterOp2	<i>Modbus Master CB2 Open request</i>
MasterCL2	<i>Modbus Master CB2 Close request</i>
MasterOp3	<i>Modbus Master CB3 Open request</i>
MasterCL3	<i>Modbus Master CB3 Close request</i>
MasterOp4	<i>Modbus Master CB4 Open request</i>
MasterCL4	<i>Modbus Master CB4 Close request</i>
MasterOp5	<i>Modbus Master CB5 Open request</i>
MasterCL5	<i>Modbus Master CB5 Close request</i>
Gen.Start	<i>General start</i>
Gen.Trip	<i>General Trip</i>
Vcc	<i>Reserved</i>
Gnd	<i>Reserved</i>
ResLog	<i>Reset signal logic</i>
P1	<i>Push-button Open (Not used with remote MMI)</i>
P2	<i>Push-button Close (Not used with remote MMI)</i>
P3	<i>Push-button Reset (Not used with remote MMI)</i>
UserTriggerOscillo	<i>User Variable for Oscillographic Recording</i>
UserVar<0>	
to	<i>User Variable</i>
UserVar<98>	

Only for "DIGITAL INPUT"

0.D1	<i>Digital Input "0.D1"</i>	<i>activated</i>
0.D1Not	<i>Digital Input "0.D1"</i>	<i>deactivated</i>
to		
0.D4	<i>Digital Input "0.D4"</i>	<i>activated</i>
0.D4Not	<i>Digital Input "0.D4"</i>	<i>deactivated</i>
1.D1	<i>Digital Input "1.D1"</i>	<i>activated</i>
1.D1Not	<i>Digital Input "1.D1"</i>	<i>deactivated</i>
to		
1.D15	<i>Digital Input "1.D15"</i>	<i>activated</i>
1.D15Not	<i>Digital Input "1.D15"</i>	<i>deactivated</i>
2.D1	<i>Digital Input "2.D1"</i>	<i>activated</i>
2.D1Not	<i>Digital Input "2.D1"</i>	<i>deactivated</i>
to		
2.D15	<i>Digital Input "2.D15"</i>	<i>activated</i>
2.D15Not	<i>Digital Input "2.D15"</i>	<i>deactivated</i>

"DI" Configuration - via MSCom2 software
Example

Name	Status	Functions
------	--------	-----------

Name

Logical Input name

Status

Logical Input status

Functions

Function available. (for multiple association use "User Variable")


Example: Setting "Digital Input"

Open "MSCom2" program and connect to the relay.

Select "Change Windows" from "Menu" button




Select "DI CONFIGURATION"


 Setting for "**BI1I>** : "**1I>**".


Name	Status	Functions
Bi1I> (Blocking Input 1I>)	Not active	1I>

"Functions"

Select "**Functions**" related to "**Bi1I>**" and press right button on mouse, select "**Value change**":



From box "Available", select "**1I>**" and press "Add".
Press "OK" for confirmation. (if Password is request, see § Password)



Outputs Relay

The output relay are fully user programmable and controlled by any protection functions and by any digital inputs.

- **0.R1** Programmable (R1)
- **0.R2** Programmable (R2)
- **0.R3** Programmable (R3)
- **0.R4** Programmable (R4)
- **0.R5** Programmable (R5)
- **0.R6** Programmable (R6)
- **1.R1** to Programmable
- **1.R14**
- **2.R1** to Programmable
- **2.R14**

Any Output Relay can be programmed to be controlled (energized) by one or more of the following functions or Digital Inputs, see § Function available

Analog output

Four analogue output are available to transmit input quantities to external instruments.

- **AN1-A** Current monitoring (I)
- **AN2-A** Voltage monitoring (V)
- **AN3-A** Available
- **AN4-A** Available

Output range :

Current [I] : 0-20mA / 0 –In (Full scale 1.2 In) .

Voltage [Vm] : 0-20mA / 0 –Vn (Full scale 1.2 Vn) .

Response time of analog output = 100ms.



Téléphone : +33 1 48 15 09 09
www.microener.com

**OPERATION MANUAL
D.C. SUBSTATION PROTECTIVE
RELAY TYPE**
DC PRO – PRO-LINE

**FDE N°:
19AA0371200**

**Rev. A
Page 86 / 107**

"OutCfg" Outputs Configuration - via MSCom2 software

"Example"

Relay	Linked functions	Logical status	Output config	Function	tON	Relay status
-------	------------------	----------------	---------------	----------	-----	--------------

"Relay"

Relay internal name

"Linked function"

Select the function for tripping the output relay (for multiple association use "User Variable")

"Logical Status"

Relay Logical status

"Output Configuration"

<i>Normally Deenergized</i>	The output relay is deenergized in normal conditions and gets energized on activation of the controlling Functional Output; reset means deenergizing.
<i>Normally Energized</i>	The output relay is energized in normal conditions and gets deenergized on activation of the controlling Functional Output; reset means energizing.

"tON - Operation Time"

This timer controls the duration of the activation of the output relay.



tON : (0.01-10)s, step 0.01s

"Relay Status"


Relay – Physical status

Functions - Operation Mode

- | | |
|------------------|---|
| Automatic | : In this mode the output relay is "operated" (energized if "N.D.", deenergized if "N.E.") when the controlling Functional Output is activated and it is reset to the "non operated" condition when the Functional Output gets deactivated but, anyhow, not before the time " TON " has elapsed (minimum duration of the operation time) |
| Manual | : In this mode the output relay is "operated" when the controlling Functional Output is activated and remains in the operated condition until a manual reset command is issued by the relay keyboard (local commands menu) or via the serial communication. In this mode the timer " TON " has no effect. |
| Impulsive | : In this mode the output relay is "operated" when the controlling Functional Output is activated and it remains in the "operated" condition (energized if "N.D.", deenergized if "N.E.") for the set time " TON " independently from the status of the controlling Functional Output. |



Select "DO CONFIGURATION"




Example: Change settings for "0.R1"

Change settings for "0.R1" : "1I>", "Normally Energized", "Pulse", "0.5".


Relay	Linked functions	Logical status	Output config	Function	tON	Relay status
0.R1 [Master board, R:1]	1I>	Off	Normally Energized	Pulse	0,5	Off



"Linked Functions"

 Select "**Linked Functions**" related to "0.R1" and press right button on mouse, select "Value change":


From box "Available", select "1I>" and press "Add".


Press "OK" for confirmation. (if Password is request, see § Password)




Output ConfigSelect "**Output Config**" related to "0.R1" and press right button on mouse, select "Value change":Select "**Normally Energized**" from combo box and press "OK" (if Password is request, see § Password)

“Function”

Select “**Function**” related to “**0.R1**” and press right button on mouse, select “**Value change**”:




Select “**Pulse**” from combo box and press “OK” (if Password is request, see § Password):

**“tON”**

Select “**tON**” related to “**0.R1**” and press right button on mouse, select “**Value change**”:



Select “**0.5**” from combo box and press “OK” (if Password is request, see § Password):



USERVAR

The "User Variable" is a result of a logical operation (OR, AND, ecc...), it can be used like other logical output.

Configuration – via MSCom2 software

Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Extra	Logical status
------	-------------	------------------	---------	-------	------------	-------	----------------

Name

Internal progressive name

User Descr.

Custom identification label for user variable

Linked functions

Selection functions

OpLogic

Operation Logic = [None, OR, AND, XOR, NOR, NAND, NOT, Ff-SR, Counter, Rise-Up, Fall-Down]

Timer

Time delay (0-600)s, step 0.01s

Timer type

<i>Delay</i>	:	Add a delay on output activation. The "Timer" is edge triggered on rise edge.
<i>Impulse P</i>	:	Monostable Positive pulse time
<i>Impulse N</i>	:	Monostable Negative pulse time
<i>Blink</i>	:	When selected output is a 50% duty cycle square wave
<i>Fall-Down</i>	:	Time added on falling output edge


Logical status

"User Variable" Logical status


Example: Setting "User Variable"

Open "MSCom2" program and connect to the relay.

Select "Change Windows" from "Menu" button



Select "**USER VARIABLE**"




Setting for "**UserVar<0>**" :

"Start Overcurrent Element", "1I>, 2I>, 3I>", "OR", "1", "Monostable P".


Name	User descr.	Linked functions	OpLogic	Timer	Timer type	Extra	Logical status
UserTrigger Oscillo	UserTrigger Oscillo		None	0	Delay	0	0
UserVar <0>	UserVar <0>		None	0	Delay	0	0

"User description" (User descr.)

Select "User descr" related to "UserVar<0>" and press right button on mouse, select "Value change":




Insert "Start Overcurrent Element" into box and press "OK":







Linked Functions

Select “**Linked Functions**” related to “UserVar<0> (“**Start Overcurrent Element**”) and press right button on mouse, select “Value change”:



Select “**1I>, 2I>, 3I>**” from “Available” box via push-button “<Add”, and press “OK”.
 For remove functions, use push-button “>Remove”.




“Operation Logic” (Oplogic)Select “**Oper Logic**” related to “UserVar<0> (“**Start Overcurrent Element**”)” and press right button on mouse, select “**Value change**”:Insert “**OR**” into box and press “**OK**”:

“Timer”

Select “**Timer**” related to “UserVar<0> (“**Start Overcurrent Element**”)” and press right button on mouse, select “**Value change**”:




Select “**1**” into box and press “**OK**”:




“Timer type”

Select “**Timer**” related to “UserVar<0> (“**Start Overcurrent Element**”)” and press right button on mouse, select “**Value change**”:



Select “**Monostable**” into box and press “OK”:



DATE AND TIME**Clock synchronization**

The internal clock has 1ms resolution and a stability of $\pm 35\text{ppm}$ in the operational temperature range.

It can be synchronized with an external time reference in the following ways:

- Using the "MSCom2" software or from the DCS with the Modbus RTU protocol.
- Through the NTP protocol, maximum 3 SNTP servers;
The relay synchronize the clock to first server available on the list "IPV4 NP server address".

Note: On power supply failure an internal battery supports the internal clock for over two years.

BATTERY

The relay is equipped with a lithium battery type "**CR2032 3V**", to support the internal clock and the oscillographic recording memory in case of programmed lack of power.

The expected minimum duration without power exceed 2 years.

ATTENTION!! Use only battery specified.

MAINTENANCE


No maintenance is required. In case of malfunctioning please contact Microelettrica Scientifica Service or the local Authorized Dealer mentioning the relay's Serial No reported in the label on relays enclosure.

POWER FREQUENCY INSULATION TEST

Every relay individually undergoes a factory insulation test according to IEC255-5 standard at 2 kV, 50 Hz 1min. Insulation test should not be repeated as it unusefully stresses the dielectrics.

When doing the insulation test, the terminals relevant to serial output, digital inputs and RTD input must always be short circuited to ground. When relays are mounted in switchboards or relay boards that have to undergo the insulation tests, the relay should be isolated. This is extremely important as discharges eventually taking place in other parts or components of the board can severely damage the relays or cause damages not immediately evident to the electronic components.

TERMINAL BLOCKS (WIRING DIAGRAM)



Power Supply

Main Unit power supply input

A 1 **A 2** **Earth 3**

Dedicated Remote Unit supply output (24V)

A 74 (+) **A 73 (-)**

Measurement Inputs

Fiber Optic

In I, V (input from MHIT transducers) **Out** I, V (output = input on fiber repeated)

Voltage Tranducer

VL 37 (+), 38 (-) **VV** 39 (+), 40 (-)

Current Tranducer

In 33 (+), 34 (-) **10In** 35 (+), 36 (-)

Frame-to-Ground Monitoring Input


Vg 43 (+), 44 (-) **Ig** 41 (+), 42 (-)

Digital Inputs

Type (Self-Powered)			Type	(-)	(+)	Type	(-)	(+)
0.D1	25/26	21	2.D1	85	86	1.D1	117	118
0.D2	25/26	22	2.D2	87	88	1.D2	119	120
0.D3	25/26	23	2.D3	89	90	1.D3	121	122
0.D4	25/26	24	2.D4	91	92	1.D4	123	124
			2.D5	93	94	1.D5	125	126
			2.D6	95	96	1.D6	127	128
			2.D7	97	98	1.D7	129	130
			2.D8	99	100	1.D8	131	132
			2.D9	101	102	1.D9	133	134
			2.D10	103	104	1.D10	135	136

Analogic Outputs

Type	(-)	(+)	Type	(-)	(+)
AN1-A	53	54	reserved	63	64
AN2-A	55	56	reserved	65	66
AN3-A	57	58	reserved	67	68
AN4-A	59	60	reserved	69	70

Output Relays

Communications terminals
Main Unit

RS485		Canbus		Connection to Remote Unit	
A (S+)	27	H	31	A	75
B (S-)	28	L	32	B	76
C	29	C	29	(Z)	77
				(Y)	78

Remote Unit

RS485		
485+		
485-		
GND		





Ethernet port

ETH 1	RJ45	ETH 2	RJ45	ETH 3	RJ45



USB


Type	A	Type	Mini


Insertion Diagram (Example)



Main Unit – Remote Unit connection detail





OVERALL DIMENSIONS**Remote Unit**



SPARE PARTS**Main Unit**

	DYNAMIC D-3500 REC HSG 6P	1318095-1
	DYNAMIC D-3500 REC HSG 4P	175363-2
	DYNAMIC D-3500 REC HSG 2P	175362-1
	DYNAMIC 3100 REC HSG 4P	1-178288-4
	DYNAMIC D-3 REC CONT 3L 16-14	1-353715-5

**Remote Unit**

	FMC 1,5 3-ST-3,5	1952270
	FMC 1,5 2-ST-3,5	1952267



MICROENER

Téléphone : +33 1 48 15 09 09
www.microener.com

**OPERATION MANUAL
D.C. SUBSTATION PROTECTIVE
RELAY TYPE**

DC PRO – PRO-LINE

**FDE N°:
19AA0371200**

**Rev. A
Page 106 / 107**

TOOLS



MINI SAHT D3000-3L

2255149-1



EXTRACTION TOOL
(DYNAMIC D-3)

234168-1





Téléphone : +33 1 48 15 09 09
www.microener.com

**OPERATION MANUAL
D.C. SUBSTATION PROTECTIVE
RELAY TYPE**
DC PRO – PRO-LINE

**FDE N°:
19AA0371200**

**Rev. A
Page 107 / 107**

ELECTRICAL CHARACTERISTICS

APPROVAL: CE

REFERENCE STANDARDS

IEC 60255 - EN50263 - CE Directive - EN/IEC61000 - IEEE C37

Dielectric test voltage	IEC 60255-5	2kV, 50/60Hz, 1 min.
Impulse test voltage	IEC 60255-5	5kV (c.m.), 2kV (d.m.) – 1,2/50µs
Insulation resistance	> 100MΩ	

Environmental Std. Ref. (IEC 60068)

Operation ambient temperature	-10°C / +55°C
Storage temperature	-25°C / +70°C
Environmental testing	
(Cold)	IEC60068-2-1
(Dry heat)	IEC60068-2-2
(Change of temperature)	IEC60068-2-14
(Damp heat, steady state)	IEC60068-2-78
	RH 93% Without Condensing AT 40°C

CE EMC Compatibility (EN50081-2 - EN50082-2 - EN50263)

Electromagnetic emission	EN55022	industrial environment	
Radiated electromagnetic field immunity test	IEC61000-4-3	level 3	80-2000MHz 10V/m
	ENV50204		900MHz/200Hz 10V/m
Conducted disturbances immunity test	IEC61000-4-6	level 3	0.15-80MHz 10V
Electrostatic discharge test	IEC61000-4-2	level 4	6kV contact / 8kV air
Power frequency magnetic test	IEC61000-4-8		1000A/m 50/60Hz
Pulse magnetic field	IEC61000-4-9		1000A/m, 8/20µs
Damped oscillatory magnetic field	IEC61000-4-10		100A/m, 0.1-1MHz
Immunity to conducted common mode disturbance 0Hz-150Khz	IEC61000-4-16	level 4	
Electrical fast transient/burst	IEC61000-4-4	level 3	2kV, 5kHz
HF disturbance test with damped oscillatory wave (1MHz burst test)	IEC60255-22-1	class 3	400pps, 2,5kV (m.c.), 1kV (d.m.)
Oscillatory waves (Ring waves)	IEC61000-4-12	level 4	4kV(c.m.), 2kV(d.m.)
Surge immunity test	IEC61000-4-5	level 4	2kV(c.m.), 1kV(d.m.)
Voltage interruptions	IEC60255-4-11		
Resistance to vibration and shocks	IEC60255-21-1	- IEC60255-21-2	10-500Hz 1g

Electric Rated Value

Accuracy at reference value of influencing factors	1% In 2% + to (to=20÷30ms @ 2xIs)	for measure for times
Rated Current	0 - ±20mA (±40) = 0 - In (2In)	
Rated Voltage	0 - 20mA (40) = 0 - Vn (2Vn)	
Average power supply consumption	< 20 VA	
Output relays	rating 5 A; Vn = 380 V A.C. resistive switching = 1100W (380V max) make = 30 A (peak) 0,5 sec. break = 0.3 A, 110 Vcc, L/R = 40 ms (100.000 op.)	



The performance and features shown in this document may be changed at any time and only commit MicroEner after confirmation.

<http://www.microener.com>